



| | | | | | | | |
|-------------|--|-----|-----------------------------|----------|---|---------------------------|--------------------------|
| B1 | Supply air temperature sensor | CW | Water cooler | QS1 | Main switch | V1 | Supply air fan |
| B2 | Extract temperature sensor | DX | Cooler | dP1, dP2 | Differential pressure switch for filter | V2 | Exhaust air fan |
| B3 | Outdoor temperature sensor | FG1 | Supply air damper actuator | RG1 | Main controller | LP | Low pressure protection |
| B4 | Exhaust temperature sensor | FG2 | Extract air damper actuator | RG2 | Extension module | HP | High pressure protection |
| B5 | Return water sensor | HE | Electric heater | RT | Rotary Heat Exchanger | SVD | Solenoid valve |
| B6, B7, B13 | Air pressure sensor | HW | Water heater coil | S1 | Heating water pump | SVR | Four-way valve |
| B8 | Airquality, CO ₂ sensor | HM | Humidifier | S2 | Cooling water pump | | |
| B9 | Humidity sensor | M1 | Rotor motor | TG1 | Hot water mixing valve actuator | | |
| B15 | Internal supply air temperature sensor | P1 | Compressor | TG2 | Cold water mixing valve actuator | | |
| CW | Water cooler | PF | Air filter | VP | Remote control panel | FUNCTIONAL DIAGRAM RHP | |
| | | | | | | | |