



## SERVICE MANUAL & TEST RUN SERVICE MANUAL


# VRF SYSTEMS INDOOR UNIT



**4-Way Cassette**  
(Type U2)



**Ceiling**  
(Type T2)



**Low Silhouette Ducted**  
(Type F2)

### Indoor Unit

	Type	15	22	28	36	45	56	60	73	90	106	140	160
U2	4-Way Cassette		S-22MU2E5A	S-28MU2E5A	S-36MU2E5A	S-45MU2E5A	S-56MU2E5A	S-60MU2E5A	S-73MU2E5A	S-90MU2E5A	S-106MU2E5A	S-140MU2E5A	S-160MU2E5A
U1	4-Way Cassette		S-22MU1E5A	S-28MU1E5A	S-36MU1E5A	S-45MU1E5A	S-56MU1E5A	S-60MU1E5A	S-73MU1E5A	S-90MU1E5A	S-106MU1E5A	S-140MU1E5A	S-160MU1E5A
Y2	4-Way Cassette 60×60	S-15MY2E5A	S-22MY2E5A	S-28MY2E5A	S-36MY2E5A	S-45MY2E5A	S-56MY2E5A						
F2	Low Silhouette Ducted	S-15MF2E5A	S-22MF2E5A S-22MF2E5A8	S-28MF2E5A S-28MF2E5A8	S-36MF2E5A S-36MF2E5A8	S-45MF2E5A S-45MF2E5A8	S-56MF2E5A S-56MF2E5A8	S-60MF2E5A S-60MF2E5A8	S-73MF2E5A S-73MF2E5A8	S-90MF2E5A S-90MF2E5A8	S-106MF2E5A S-106MF2E5A8	S-140MF2E5A S-140MF2E5A8	S-160MF2E5A S-160MF2E5A8
T2	Ceiling				S-36MT2E5A	S-45MT2E5A	S-56MT2E5A		S-73MT2E5A		S-106MT2E5A	S-140MT2E5A	
K2	Wall Mounted	S-15MK2E5A	S-22MK2E5A	S-28MK2E5A	S-36MK2E5A								
K1	Wall Mounted					S-45MK1E5A	S-56MK1E5A		S-73MK1E5A		S-106MK1E5A		
M1	Slim Low Static Ducted	S-15MM1E5A	S-22MM1E5A	S-28MM1E5A	S-36MM1E5A	S-45MM1E5A	S-56MM1E5A						

### Indoor Unit

	Type	180	224	280
E2	High Static Pressure Ducted	S-180ME2E5	S-224ME2E5	S-280ME2E5

● Connectable outdoor unit lineup

This document is the Service Manual of the indoor unit.

For outdoor unit, refer to the Service Manual of the outdoor unit.

■ For Europe

Type	Outdoor Unit Type	4 hp	5 hp	6 hp	8 hp	10 hp
ME1	2WAY VRF System				U-8ME1E81	U-10ME1E81
MF2	3WAY VRF System				U-8MF2E8	U-10MF2E8
LE1	Mini VRF System	U-4LE1E5	U-5LE1E5	U-6LE1E5		
		U-4LE1E8	U-5LE1E8	U-6LE1E8		

Type	Outdoor Unit Type	12 hp	14 hp	16 hp	18 hp	20 hp
ME1	2WAY VRF System	U-12ME1E81	U-14ME1E81	U-16ME1E81	U-18ME1E81	U-20ME1E81
MF2	3WAY VRF System	U-12MF2E8	U-14MF2E8	U-16MF2E8		

■ For Oceania

Type	Outdoor Unit Type	4 hp	5 hp	6 hp	8 hp	10 hp
ME1	2WAY VRF System				U-8ME1R8	U-10ME1R8
					U-8ME1R8B	U-10ME1R8B
					U-8ME1R8BE*	U-10ME1R8BE*
MF2	3WAY VRF System				U-8MF2R7	U-10MF2R7
					U-8MF2R7B	U-10MF2R7B
					U-8MF2R7BE*	U-10MF2R7BE*
LE1	Mini VRF System	U-4LE1R5	U-5LE1R5	U-6LE1R5		
		U-4LE1R5E*	U-5LE1R5E*	U-6LE1R5E*		
		U-4LE1R8	U-5LE1R8	U-6LE1R8		
		U-4LE1R8E*	U-5LE1R8E*	U-6LE1R8E*		

Type	Outdoor Unit Type	12 hp	14 hp	16 hp	18 hp	20 hp
ME1	2WAY VRF System	U-12ME1R8	U-14ME1R8	U-16ME1R8	U-18ME1R8	U-20ME1R8
		U-12ME1R8B	U-14ME1R8B	U-16ME1R8B	U-18ME1R8B	U-20ME1R8B
		U-12ME1R8BE*	U-14ME1R8BE*	U-16ME1R8BE*	U-18ME1R8BE*	U-20ME1R8BE*
MF2	3WAY VRF System	U-12MF2R8	U-14MF2R8			
		U-12MF2R8B	U-14MF2R8B			
		U-12MF2R8BE*	U-14MF2R8BE*			

\* Salt-Air Damage Resistant Specifications.

■ For Asia

Type	Outdoor Unit Type	4 hp	5 hp	6 hp	8 hp	10 hp
ME1	2WAY VRF System				U-8ME1H7	U-10ME1H7
					U-8ME1H7E*	U-10ME1H7E*
LE1	Mini VRF System	U-4LE1H4	U-5LE1H4	U-6LE1H4		
		U-4LE1H4E*	U-5LE1H4E*	U-6LE1H4E*		
		U-4LE1H7	U-5LE1H7	U-6LE1H7		
		U-4LE1H7E*	U-5LE1H7E*	U-6LE1H7E*		

Type	Outdoor Unit Type	12 hp	14 hp	16 hp	18 hp	20 hp
ME1	2WAY VRF System	U-12ME1H8	U-14ME1H8	U-16ME1H8	U-18ME1H8	U-20ME1H8
		U-12ME1H8E*	U-14ME1H8E*	U-16ME1H8E*	U-18ME1H8E*	U-20ME1H8E*

\* Salt-Air Damage Resistant Specifications.

November 2014

## IMPORTANT!

### Please Read Before Starting

This air conditioner must be installed by the sales dealer or installer.

This information is provided for use only by authorized persons.

**For safe installation and trouble-free operation, you must:**

- Carefully read this instruction booklet before beginning.
- Follow each installation or repair step exactly as shown.
- This air conditioner shall be installed in accordance with National Wiring Regulations.
- The product meets the technical requirements of EN/IEC 61000-3-3.
- Pay close attention to all warning and caution notices given in this manual.



**WARNING**

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



**CAUTION**

This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

### If Necessary, Get Help

These instructions are all you need for most installation sites and maintenance conditions. If you require help for a special problem, contact our sales/service outlet or your certified dealer for additional instructions.

### In Case of Improper Installation

The manufacturer shall in no way be responsible for improper installation or maintenance service, including failure to follow the instructions in this document.

## SPECIAL PRECAUTIONS




**WARNING When Wiring**



**ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH. ONLY A QUALIFIED, EXPERIENCED ELECTRICIAN SHOULD ATTEMPT TO WIRE THIS SYSTEM.**

- Do not supply power to the unit until all wiring and tubing are completed or reconnected and checked.
- Highly dangerous electrical voltages are used in this system. Carefully refer to the wiring diagram and these instructions when wiring. Improper connections and inadequate grounding can cause **accidental injury or death.**

- Connect all wiring tightly. Loose wiring may cause overheating at connection points and a possible fire hazard.
- Provide a power outlet to be used exclusively for each unit.
- Provide a power outlet exclusively for each unit, and full disconnection means having a contact separation by 3 mm in all poles must be incorporated in the fixed wiring in accordance with the wiring rules.
- To prevent possible hazards from insulation failure, the unit must be grounded. 
- This equipment is strongly recommended to be installed with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD). Otherwise, it may cause electrical shock and fire in case of equipment breakdown or insulation breakdown.

### When Transporting

- It may need two or more people to carry out the installation work.
- Be careful when picking up and moving the indoor and outdoor units. Get a partner to help, and bend your knees when lifting to reduce strain on your back. Sharp edges or thin aluminum fins on the air conditioner can cut your fingers.

### When Installing...

Select an installation location which is rigid and strong enough to support or hold the unit, and select a location for easy maintenance.

#### ...In a Room

Properly insulate any tubing run inside a room to prevent "sweating" that can cause dripping and water damage to walls and floors.



**CAUTION**

Keep the fire alarm and the air outlet at least 1.5 m away from the unit.

### ...In Moist or Uneven Locations

Use a raised concrete pad or concrete blocks to provide a solid, level foundation for the outdoor unit. This prevents water damage and abnormal vibration.

### ...In an Area with High Winds

Securely anchor the outdoor unit down with bolts and a metal frame. Provide a suitable air baffle.

### ...In a Snowy Area (for Heat Pump-type Systems)

Install the outdoor unit on a raised platform that is higher than drifting snow. Provide snow vents.

### ...At least 2.5 m

Indoor unit of this air conditioner shall be installed in a height of at least 2.5 m.

### ...In laundry rooms

Do not install in laundry rooms. Indoor unit is not drip proof.

## When Connecting Refrigerant Tubing

Pay particular attention to refrigerant leakages.




### WARNING

- When performing piping work, do not mix air except for specified refrigerant (R410A) in refrigeration cycle. It causes capacity down, and risk of explosion and injury due to high tension inside the refrigerant cycle.
- If the refrigerant comes in contact with a flame, it produces a toxic gas.
- Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury, etc.
- Ventilate the room immediately, in the event that is refrigerant gas leaks during the installation. Be careful not to allow contact of the refrigerant gas with a flame as this will cause the generation of toxic gas.

- Keep all tubing runs as short as possible.
- Use the flare method for connecting tubing.
- Apply refrigerant lubricant to the matching surfaces of the flare and union tubes before connecting them, then tighten the nut with a torque wrench for a leak-free connection.
- Check carefully for leaks before starting the test run.
- Do not leak refrigerant while piping work for an installation or re-installation, and while repairing refrigeration parts. Handle liquid refrigerant carefully as it may cause frostbite.

## When Servicing

- Turn the power OFF at the main power box (mains), wait at least 10 minutes until it is discharged, then open the unit to check or repair electrical parts and wiring. 
- Keep your fingers and clothing away from any moving parts.
- Clean up the site after you finish, remembering to check that no metal scraps or bits of wiring have been left inside the unit.



### WARNING

- This product must not be modified or disassembled under any circumstances. Modified or disassembled unit may cause fire, electric shock or injury.
- Do not clean inside the indoor and outdoor units by users. Engage authorized dealer or specialist for cleaning.
- In case of malfunction of this appliance, do not repair by yourself. Contact to the sales dealer or service dealer for a repair.



## CAUTION





- Ventilate any enclosed areas when installing or testing the refrigeration system. Leaked refrigerant gas, on contact with fire or heat, can produce dangerously toxic gas.
- Confirm after installation that no refrigerant gas is leaking. If the gas comes in contact with a burning stove, gas water heater, electric room heater or other heat source, it can cause the generation of toxic gas.

## Others

---



## CAUTION

- Do not sit or step on the unit, you may fall down accidentally. 
- Do not touch the air inlet or the sharp aluminum fins of the outdoor unit. You may get injured. 
- Do not stick any object into the FAN CASE. You may be injured and the unit may be damaged.   


## NOTICE

The English text is the original instructions. Other languages are translations of the original instructions.

This notice is only for High Static Pressure Ducted type.

---

## SPECIAL PRECAUTIONS

---



### WARNING When Wiring

---



**ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH. ONLY A QUALIFIED, EXPERIENCED ELECTRICIAN SHOULD ATTEMPT TO WIRE THIS SYSTEM.**

- This equipment is strongly recommended to be installed with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD). Otherwise, it may cause electrical shock and fire in case of equipment breakdown or insulation breakdown.

### When Installing...

---

Check the following to use the FRESH AIR INTAKE MODE.

#### WARNING

- Install the outdoor air intake port in an area where the combustion gas cannot be inhaled. If safety issues exist, the room becomes oxygen-deprived and this will cause the fatal accident.
- Do not make air around the discharge air outlet lead to the outdoor air intake port. The indoor air is contaminated and this causes the health problem.

#### CAUTION

- In the area where the temperature inside the unit becomes below 0°C due to cold air in cold climates, install the electrical damper onto the outdoor air duct for antifreeze measurement.
- Select the installation location where the temperature and humidity are within the usability range. If the relative humidity inside the ceiling exceeds 80%, measure against the condensation (additional insulation, etc.)
- Be sure to insulate the piping to protect the condensation. In the case of insufficiency, water may enter the building and this may cause damage to the furniture or interiors, etc.
- Install the piping to be slightly slanting to the outdoor side. In the case of insufficiency, rain drops may enter the building and damage the furniture or cause electric shock and fire.
- Avoid the area where sulfurous acid gas, corrosive gas or salt erosion potentially occur. This may cause corrosion to the copper tube and brazing part. As a result, refrigerant gas may leak.

# CONTENTS

<b>Section 1:</b>	<b>CONTROL FUNCTIONS-Outdoor Unit</b> .....	<b>1-1</b>
	* Refer to the Service Manual of Outdoor Unit.	
<b>Section 2:</b>	<b>CONTROL FUNCTIONS-Indoor Unit</b> .....	<b>2-1</b>
	1. Room Temperature Control .....	2-2
	2. Heating Standby .....	2-5
	3. Automatic Fan Speed Control .....	2-6
	4. Indoor Unit MOV Control .....	2-7
	5. Drain Pump Control .....	2-7
	6. Automatic Heating / Cooling Control .....	2-8
	7. Discharge Air Temperature Control .....	2-9
	8. RAP Valve Kit Control .....	2-9
	9. Automatic Flap Control .....	2-10
	10. Filter Sign .....	2-10
	11. Electric Heater Control .....	2-11
	12. Fan Control during Dry Mode .....	2-11
	13. Ventilation Fan Output .....	2-12
	14. T10 Terminal .....	2-12
	15. Parameter .....	2-13
	16. Indoor Unit Control PCB .....	2-14
<b>Section 3:</b>	<b>OUTDOOR UNIT REPAIR PROCEDURES</b> .....	<b>3-1</b>
	* Refer to the Service Manual of Outdoor Unit.	
<b>Section 4:</b>	<b>OUTDOOR UNIT MAINTENANCE REMOTE CONTROLLER</b> .....	<b>4-1</b>
	* Refer to the Service Manual of Outdoor Unit.	
<b>Section 5:</b>	<b>REMOTE CONTROLLER FUNCTIONS</b> .....	<b>5-1</b>
	1. Simple Settings Function .....	5-2
	2. Detailed Settings Function .....	5-9
	3. Remote Controller Servicing Functions .....	5-44
<b>Section 6:</b>	<b>TROUBLE DIAGNOSIS</b> .....	<b>6-1</b>
	* Refer to the Service Manual of Outdoor Unit.	
<b>Section 7:</b>	<b>TEST RUN from the remote controller</b> .....	<b>7-1</b>
	1. Test Run .....	7-2
	2. Auto Address Setting .....	7-4

– MEMO –



## 1. CONTROL FUNCTIONS-Outdoor Unit

\* Refer to the Service Manual of Outdoor Unit.



**2. CONTROL FUNCTIONS-Indoor Unit**

1. Room Temperature Control ..... 2-2

2. Heating Standby ..... 2-5

3. Automatic Fan Speed Control ..... 2-6

4. Indoor Unit MOV Control ..... 2-7

5. Drain Pump Control ..... 2-7

6. Automatic Heating / Cooling Control ..... 2-8

7. Discharge Air Temperature Control ..... 2-9

8. RAP Valve Kit Control ..... 2-9

9. Automatic Flap Control ..... 2-10

10. Filter Sign ..... 2-10

11. Electric Heater Control ..... 2-11

12. Fan Control during Dry Mode ..... 2-11

13. Ventilation Fan Output ..... 2-12

14. T10 Terminal ..... 2-12

15. Parameter ..... 2-13

16. Indoor Unit Control PCB ..... 2-14



# 1. Room Temperature Control

## 1. Room Temperature Control

- The body sensor or remote controller sensor detects temperature in the room. The detected temperature is called the room temperature. The body sensor is the one contained in the indoor unit.

	Body sensor is enabled	Remote controller sensor is enabled
Set temp.	Set temp. in remote controller	Set temp. in remote controller
Detected temp. by sensor	Detected temp. by body sensor	Detected temp. by remote controller sensor
Room temp.	Detected temp. by body sensor - *correction temp.	Detected temp. by remote controller sensor

- The thermostat is turned ON or OFF according to the following  $\Delta T$ .

$\Delta T$ (Cooling)	$\Delta T = \text{room temp.} - \text{set temp. (set temp. in remote controller)}$
$\Delta T$ (Heating)	$\Delta T = \text{set temp.} - \text{room temp.}$

※ Correction temperature (only during heating)

If the indoor unit is installed on the ceiling, temperature near the ceiling is higher than near the floor. When the body sensor is enabled, lower temperature near the floor must be considered. To correct this difference in temperature, the correction temperature is used.

The factory setting for the correction temperature is different depending on the model. Refer to "15. Parameter".

Example: Cooling temperature correction

4-Way cassette (correction temperature: 0 degrees)

Body sensor is enabled

Set temp. in remote controller	28°C	28°C	28°C
Detected temp. by sensor	30.0°C	27.5°C	27.0°C
Detected temp. by body sensor	30.0°C	27.5°C	27.0°C
Detected temp. by remote controller sensor	30.0°C	27.5°C	27.0°C
Room temp. = temp. detected by body sensor	30.0°C =30.0	27.5°C =27.5	27.0°C =27.0
$\Delta T$	+2.0deg	-0.5deg	-1.0deg
	Thermostat ON	Thermostat ON	Thermostat OFF

Example: Heating temperature correction

4-Way cassette (correction temperature: 4 degrees)

Body sensor is enabled

Set temp. in remote controller	20°C	20°C	20°C
Detected temp. by sensor	17.0°C	22.0°C	25.0°C
Detected temp. by body sensor	17.0°C	22.0°C	25.0°C
Detected temp. by remote controller sensor	13.0°C	18.0°C	21.0°C
Room temp. = temp. detected by body sensor - 4 deg	13.0°C =17.0-4 deg	18.0°C =22.0-4 deg	21.0°C =25.0-4 deg
$\Delta T$	+7.0deg	+2.0deg	-1.0deg
	Thermostat ON	Thermostat ON	Thermostat OFF


Remote controller sensor is enabled

Set temp. in remote controller	28°C	28°C	28°C
Detected temp. by sensor	30.0°C	27.5°C	27.0°C
Detected temp. by body sensor	30.0°C	27.5°C	27.0°C
Detected temp. by remote controller sensor	30.0°C	27.5°C	27.0°C
Room temp. = temp. detected by remote controller sensor	30.0°C =30.0	27.5°C =27.5	27.0°C =27.0
$\Delta T$	+2.0deg	-0.5deg	-1.0deg
	Thermostat ON	Thermostat OFF	Thermostat OFF


Remote controller sensor is enabled

Set temp. in remote controller	20°C	20°C	20°C
Detected temp. by sensor	17.0°C	20.5°C	21.0°C
Detected temp. by body sensor	21.0°C	24.5°C	25.0°C
Detected temp. by remote controller sensor	17.0°C	20.5°C	21.0°C
Room temp. = temp. detected by remote controller sensor	17.0°C =17.0	20.5°C =20.5	21.0°C =21.0
$\Delta T$	+3.0deg	-0.5deg	-1.0deg
	Thermostat ON	Thermostat OFF	Thermostat OFF

Body sensor is enabled



Remote controller sensor is enabled



- ① The thermostat does not turn OFF for 3 minutes after it turns ON.
- ② The thermostat does not turn ON 1 to 3 minutes after it turns OFF.
- ③ The thermostat does not turn OFF for 60 minutes during the test run mode. (Forced thermostat ON)  
\*However, the thermostat turns OFF if an alarm occurs.

## < FRESH AIR INTAKE MODE (Type E2) >

### Intake Air Temperature Control

This product brings outdoor fresh air into the building and adjusts and supplies the air with nearly current indoor temperature.


#### ● Automatic cooling and heating operation mode

Due to the temperature difference between the outdoor air and preset temperature in remote controller, cooling or heating operation can be automatically selected.

In the case of group control, the setting is possible when all of the indoor units in the same refrigerant circuit consist of one group.

- ① **Cooling operation mode** : In case that the outdoor temperature is 5°C higher than the preset temperature in remote controller.
- ② **Fan operation mode** : In case that the outdoor temperature and preset temperature in remote controller are within  $\pm 5^\circ\text{C}$ .
- ③ **Heating operation mode** : In case that the outdoor temperature is 5°C lower than the preset temperature in remote controller.

Example: In case that the preset temperature in remote controller set at 20°C



#### ● Cooling operation mode

It is recommended that the temperature setting in remote controller be more than 24°C.

If the intake air temperature is getting higher than the preset temperature in remote controller, the unit operates in cooling mode. On the contrary, if the intake air temperature becomes lower than the preset temperature, the unit operates in fan mode.

#### ● Heating operation mode

It is recommended that the temperature setting in remote controller be set at 16°C.

If the intake air temperature is getting lower than the preset temperature in remote controller, the unit operates in heating mode. On the contrary, if the intake air temperature becomes higher than the preset temperature, the unit operates in fan mode.


#### ● Fan operation mode

In the moderate climates, supply of fresh outdoor air can provide as passive cooling.

#### NOTE

In general, it is recommended that you set in the automatic cooling and heating operation mode.

## 2. Heating Standby

● In heating mode, the indoor fan speed decreases to prevent cold air discharge from the indoor unit. During this time,  (heating standby) is displayed on the remote controller.



① This condition occurs in the following cases.

- Thermostat OFF
- Defrosting operation
- Indoor heat exchanger liquid temperature (E1) < 28°C and discharge air temperature < 25°C just after heating operation started

The fan speed may sometimes increase when this condition continues for 6 minutes.

② The fan mode increases when the heat exchanger liquid temperature (E1) or discharge air temperature increases.



※ The fan mode is selected based on the discharge air temperature and E1 temperature as shown in the below figure. If the E1 temperature and discharge air temperature are different, the higher temperature is used.



※ The function of "HH" is identical to the automatic fan speed mode.

## 3. Automatic Fan Speed Control

- ① The indoor fan mode is controlled as shown below during the automatic fan mode.
- ② The fan mode does not change for 3 minutes during cooling operation and 1 minute during heating operation once it is changed.
- ③ The values in the parenthesis are when the remote controller sensor is enabled.





#### 4. Indoor Unit MOV Control

- For details, refer to the Service Manual of Outdoor Unit.
- ※ The MOV is at 480 pulses in the following cases.
  - ① At the time of factory shipment
  - ② Just after the indoor unit power cord is connected.

#### 5. Drain Pump Control

The drain pump operates in the following conditions.

- ① Cooling thermostat ON
- ② The float switch worked.
- ③ The drain pump may often operate for a while when the cooling thermostat turns OFF or the indoor unit is stopped.
- ④ The drain pump can be turned on when the cooling thermostat is OFF if the setting is made to prevent water collected in the drain pan for a long time. For details, refer to "5-2. Detailed Settings Function."
- ⑤ The indoor unit heat exchanger liquid temperature (E1) is less than 0°C when the cooling thermostat is OFF or the indoor unit is stopped.

※ The drain pump operates for 20 minutes once it starts operating.

## 6. Automatic Heating / Cooling Control

- This function is only valid as long as one indoor unit is installed within one refrigerant system or all indoor units are controlled within a group control.
  - When operating in a group control, the sub-indoor units become the same operation mode of the main unit.
  - As for the indoor units in a group control, install them in the same air conditioning circumstances.
  - Use the temperature sensor which is built-in sensor of the indoor unit.
- ① When operation starts, heating or cooling is selected according to the set temperature and the room temperature.
    - Room temperature  $\geq$  Set temperature + 1  $\rightarrow$  Cooling
    - Set temperature - 1 < Room temperature  $\leq$  Set temperature + 1  $\rightarrow$  Monitoring mode (\*1)
    - Room temperature < Set temperature - 1  $\rightarrow$  Heating

\*1: If the difference between the room temperature and set temperature is small when operation starts, the cooling thermostat remains in standby status (OFF) until the temperature difference increases. When the temperature difference increases, either cooling operation or heating operation is selected. This standby status is known as "monitoring mode."

- ② After operation starts in the selected operating mode, the set temperature is automatically shifted by +2°C (\*3) (cooling operation) or -2°C (\*3) (heating operation).

Example: Temperature set on the remote controller is 20°C.

Control temp. for cooling	22°C	* 20°C (temperature set) + 2°C (*3)
Remote controller display	20°C	
Control temp. for heating	18°C	* 20°C (temperature set) - 2°C (*3)


- ③ Operating mode changes (heating  $\rightarrow$  cooling, cooling  $\rightarrow$  heating) which occur during operation as a result of temperature changes are handled as shown below.
  - Heating  $\rightarrow$  cooling: Room temperature  $\rightarrow$  Shifted set temperature (set temperature + 2°C (\*3)) + 0.5°C
  - Cooling  $\rightarrow$  heating: Room temperature  $\rightarrow$  Shifted set temperature (set temperature - 2°C (\*3)) - 1.0°C

Example: Temperature set on the remote controller is 20°C.

	Operating mode change	Shifted set temp.
1	Heating $\rightarrow$ Cooling	$20 + 2 (*3) + 0.5 = 22.5^\circ\text{C}$ or higher (*2)
2	Cooling $\rightarrow$ Heating	$20 - 2 (*3) - 1.0 = 17^\circ\text{C}$ or lower

\*2: During heating operation when the body sensor is used, a temperature shift is applied to the intake temperature detected by the sensor, in consideration of the difference in temperature at the top and bottom of the room. (Refer to the "Room Temperature Control" item.) If this intake shift temperature is 4°C, then the heating  $\rightarrow$  cooling change occurs when the temperature detected by the body sensor is 26.5°C or higher.

- ④ Cooling (heating) operation does not change if the room temperature changes from area C  $\rightarrow$  A (or A  $\rightarrow$  C) within 10 minutes after the compressor turns OFF. (Monitoring mode is excepted.)
- ⑤ When the heating/cooling change occurs, the 4-way valve switches approximately 30 to 50 seconds after the compressor turns ON.



\*3: Correction temp. is different depending on the model.  
See the right column [ Indoor item code "1E" ] under the section "15. Parameter".

### 7. Discharge Air Temperature Control

Discharge air temperature is controlled using the indoor unit discharge air temperature sensor. The discharge air temperature is set in the EEPROM on the PCB. The setting is different depending on the model.

Discharge air temperature setting (at the time of factory shipment)

Indoor unit type	Discharge air temperature setting	
	Cooling	Heating
Y2, F2, M1, E2, K2, U2	12°C	50°C
E2 (FRESH AIR INTAKE MODE)	18°C	45°C

- Condition for Thermostat ON → OFF under discharge air temperature control
  - ① Temperature less than “Discharge air temperature setting – 2°C” is continuously detected for 20 minutes in cooling mode
  - ② Temperature more than “Discharge air temperature setting + 2°C” is continuously detected for 20 minutes in heating mode
  - ③ Temperature less than “Discharge air temperature setting – 3.5°C” is continuously detected for 7 minutes in cooling mode
  - ④ Temperature more than “Discharge air temperature setting + 3.5°C” is continuously detected for 7 minutes in heating mode
- ※ There is no priority order between the room temperature control and discharge air temperature control.

- Relation between thermostat ON / OFF and room temperature control / discharge air temperature control
 

Thermostat turns OFF: Either room temperature control or discharge air temperature control satisfies thermostat OFF condition.

Thermostat turns ON: Both of room temperature control and discharge air temperature control satisfy thermostat ON condition.

### 8. RAP Valve Kit Control


※ The RAP valve kit is sometimes used in the 2-Way system.

The RAP valve kit prevents refrigerant from collecting in the indoor heat exchanger when the indoor unit is stopped. The following table shows the RAP valve kit operation.

Operating mode		RAP valve kit
Stopped		OFF
Fan		OFF
Cooling	Thermostat ON	OFF
	Thermostat OFF	OFF
Heating	Thermostat ON	ON
	Thermostat OFF	OFF

### 9. Automatic Flap Control

- The flap position can be selected from 5 positions.



Operating mode	Flap position
Cooling / Dry	F1 • F2 • F3 *
Fan	F1 • F2 • F3 • F4 • F5
Heating	F1 • F2 • F3 • F4 • F5

\* Type U2 can set the flap position F4 and F5

- ① The flap moves to the following position automatically when the indoor unit is stopped.  
 F0 (close): Types K1, K2, T2, U1, U2, Y2  
 F5: Models other than the above
- ② The flap closes once and moves to the set position when the operating mode is changed.
  - ※ If the flap position cannot be adjusted because of a problem, only the swing operation can be used. Check the flap and flap motor.
  - ※ The swing operation can be set for the flap.

### 10. Filter Sign


- ① When accumulated operating time of the indoor unit reaches the set time, the filter sign appears on the remote controller. Clean the filter.  
 See page 5-6.
- ② After cleaning the filter, press the filter button on the remote controller once. The filter sign turns off.

### 11. Electric Heater Control

The electric heater control is performed when an electric heater is installed with the indoor unit.

The heater turns ON when all of the following conditions (1 to 3) are satisfied in heating mode (thermostat ON).


- ① Body sensor enabled: ON when  $\Delta T \geq 4.0^{\circ}\text{C}$  (Remote controller sensor enabled: ON when  $\Delta T \geq 2.0^{\circ}\text{C}$ )  
OFF when  $\Delta T \leq 1.0$  degree
- ② ON: body sensor temperature  $< 26^{\circ}\text{C}$ , OFF: body sensor temperature  $\geq 29^{\circ}\text{C}$
- ③ ON: discharge air temperature  $< 40^{\circ}\text{C}$ , OFF: discharge air temperature  $\leq 45^{\circ}\text{C}$



※ For details on  $\Delta T$ , refer to “1. Room Temperature Control”.

### 12. Fan Control during Dry Mode

The fan control during dry mode is as follows.



A: Fan mode set in the remote controller

B: Fan mode is L during thermostat ON, LL during thermostat OFF

※ For details on  $\Delta T$ , refer to “1. Room Temperature Control”.

### 13. Ventilation Fan Output

- The output of ventilation turns ON when the indoor unit turns ON. Also, when the indoor unit turns OFF, the output of the ventilation turns OFF.
- The ventilation fan can also be turned ON and OFF using the ventilation button on the remote controller.

Refer to the operating instructions supplied with the remote controller.

To enable this function, set the indoor EEPROM DN31 to "0001" in advance.

### 14. T10 Terminal

Using the T10 terminal, each indoor unit can be operated or stopped separately. Also, operating condition can be checked.

## 15. Parameter

Type	Model	Indoor item code "06"	Indoor item code "1E"
		Heating intake temperature shift	Temperature shift for cooling / heating change in auto heat / cool mode
		Setting at time of factory shipment	Setting at time of factory shipment
U1, U2	4-Way Cassette	4 deg	2 deg
Y2	4-Way Cassette 60x60	4 deg	2 deg
F2	Low Silhouette Ducted	4 deg	2 deg
T2	Ceiling	4 deg	2 deg
K1	Wall Mounted	2 deg	2 deg
K2	Wall Mounted	3 deg	2 deg
M1	Slim Low Static Ducted	4 deg	2 deg
E2	High Static Pressure Ducted	4 deg	2 deg
	High Static Pressure Ducted (FRESH AIR INTAKE MODE)	0 deg	5 deg



# 16. Indoor Unit Control PCB

## Indoor Unit Control PCB Switches and Functions

### Indoor unit control PCB

**T10:** **6P plug (yellow):** Used for remote control. (Refer to the remote control section.)

(CN061) Control items: (1) Start/stop input (2) Remote controller prohibit input  
(3) Start signal output (4) Alarm signal output

**EXCT:** **2P plug (red):** Can be used for demand control. When input is present, forces the unit to operate with the thermostat OFF.

**DISP:** (CN072) **2P plug (white):**  
(CN063) **2P plug (black) Type T2, F2, U1:**  
(CN062) **6P plug (black) 3-4pin Type U2 only:**

Short-circuiting this plug allows the unit to be operated by the remote controller, even if it is not connected to an outdoor unit.

(In this case, alarm "E04," which indicates trouble in the serial communication between the indoor and outdoor unit, does not occur.)

**CHK:** (CN071) **2P plug (white):**  
(CN062) **2P plug (black) Type T2, F2, U1:**  
(CN062) **6P plug (black) 5-6pin Type U2 only:**

Test pin. Short-circuiting this pin allows the indoor FM (H fan speed), drain pump, flap motor (F1 position), and electronic expansion valve full-open position to be checked.

However this function turns OFF if the indoor unit protection mechanism is activated.

The unit can be operated even if the remote controller and outdoor unit are not connected.

However even if the remote controller cannot be connected, it cannot be used to operate the unit.

This function can be used for short-term tests.

**JP1:** **Jumper wire:** Allows selection of the T10 terminal start/stop signal. (Refer to the remote control section.)  
(J001) Status at shipment : Pulse signal  
Jumper wire cut : Static signal (continuous signal)

**FAN DRIVE 2P plug (white):** This terminal sends a signal to the ventilation fan when the FAN button on the wired remote controller is used to operate a commercially-available ventilation fan.  
(CN032) (Refer to the remote control section.)

Use a ventilation fan which can accept no-voltage A contact as the external input signal.

**Power LED: LED (red):** Illuminates when power is supplied. Blinks when there is a failure in the EEPROM (IC10: nonvolatile memory). (D002)

**EEPROM: Nonvolatile memory:** Memory which stores the unit type data and other information.


(IC10) When the PCB is replaced, remove the EEPROM from the old PCB and install it onto the new PCB.

If an IC failure occurs, replace with a new IC which was provided with the service PCB, and set the necessary information from the wired remote controller.


(For the procedure, refer to the servicing technical materials.)

- The indoor unit power terminal plate may be a 7P type, 6P type or may be a 5P type. (Refer to the figure at below.)


The basic wiring diagram shows the 7P-type terminal plate.  
Therefore the terminal plate may differ from the illustrations.




Type U2




Type F2, T2, U1




Type M1




Type K1



Type K2




Type E2



Type Y2




## 1. Wall Mounted (Type K2) CR-22MK2E5 : S-15MK2E5A / S-22MK2E5A / 28MK2E5A / 36MK2E5A




## 2. Wall Mounted (Type K1) CR-K186XH : S-45MK1E5A / 56MK1E5A / 73MK1E5A / 106MK1E5A


2



## 3. 4-Way Cassette (Type U1) : S-22~160MU1E5A Ceiling (Type T2) : S-36~140MT2E5A F747931




## 4. Low Silhouette Ducted (Type F2) F747938 : S-15~160MF2E5A




2

## 5. 4-Way Cassette 60×60 (Type Y2) CR-22MY2E5, POW-22MY2E5 : S-15~56MY2E5A

2




CR-22MY2E5



POW-22MY2E5


## 6. High Static Pressure Ducted (Type E2) CR-280ME2E5 : S-180ME2E5 / 224ME2E5 / 280ME2E5




## 7. Slim Low Static Ducted (Type M1) A748023 :

S-15MM1E5A / 22MM1E5A / 28MM1E5A / 36MM1E5A / 45MM1E5A / 56MM1E5A

2



## 8. 4-Way cassette (Type U2) ACXA73-02060 : S-22MU2E5A / 28MU2E5A / 36MU2E5A / 45MU2E5A / 56MU2E5A / 60MU2E5A / 73MU2E5A / 90MU2E5A / 106MU2E5A / 140MU2E5A / 160MU2E5A







### **3. OUTDOOR UNIT REPAIR PROCEDURES**

\* Refer to the Service Manual of Outdoor Unit.



## 4. OUTDOOR UNIT MAINTENANCE REMOTE CONTROLLER

\* Refer to the Service Manual of Outdoor Unit.



## 5. REMOTE CONTROLLER FUNCTIONS

1. Simple Settings Function .....	5-2
2. Detailed Settings Function .....	5-9
3. Remote Controller Servicing Functions .....	5-44

Regarding the content of the remote controller mentioned below:

Refer to the **2WAY VRF SYSTEM Technical Data (TD831159)** .

- Main Operating Functions
- Wireless Remote Controller (CZ-RWSU2, CZ-RWST2, CZ-RWSL2, CZ-RWSC2, CZ-RWSY2)
- Timer Remote Controller (CZ-RTC2)
- Simplified Remote Controller (CZ-RE2C2, CZ-RELC2)
- System Controller (CZ-64ESMC2)
- Schedule Timer (CZ-ESWC2)
- ON/OFF Controller (CZ-ANC2)
- Intelligent Controller (CZ-256ESMC2)
- Communication Adapter (CZ-CFUNC2)
- Remote Sensor (CZ-CSRC2)
- LonWorks Interface (CZ-CLNC2)
- Seri-Para I/O Unit for outdoor unit (CZ-CAPDC2)
- Seri-Para I/O Unit for each indoor unit (CZ-CAPBC2)
- Interface Adapter (CZ-CAPC2)
- Web Interface (CZ-CWEBC2)
- Intelligent Management System
  - Basic Software (CZ-CSWKC2)
  - Distribution Ratio Software (CZ-CSWAC2)
  - Web Software (CZ-CSWWC2)
  - Layout Display Software (CZ-CSWGC2)
  - BACnet™ Software (CZ-CSWBC2)

Refer to the **VRF SYSTEM INDOOR UNIT Technical Data (TD831193)** .

- High-spec Wired Remote Controller (CZ-RTC3)
- ECONAVI Sensor (CZ-CENSC1)
- Timer Remote Controller (CZ-RTC4)
- High-spec Wired Remote Controller (CZ-RTC5A)

# 1. Simple Settings Function

- This allows the filter lifetime, operating mode priority change, central control address, and other settings to be made for an individual or group-control indoor unit to which the remote controller used for simple settings is connected.

When simple settings mode is engaged, operation stops at the individual or group-control indoor unit to which the remote controller for simple settings is connected.

## <Procedure of CZ-RTC2>

- Press and hold the **SET** and **HOME** buttons simultaneously for 4 seconds or longer.
- "SET DATA," unit No. "**1-1**" (or "**ALL**" in the case of group control), item code "**01**," and settings data "**00XX**" are displayed blinking on the remote controller LCD display (Fig. 1-1). At this time, the indoor unit fan (or all indoor unit fans in the case of group control) begins operating.
- If group control is in effect, press the **UNIT** button and select the address (unit No.) of the indoor unit to set. At this time, the fan at the indoor unit begins operating.
  - \* If unit No. "**ALL**" is displayed, the same setting will be made for all indoor units.

- Press the temperature setting **▲** / **▼** buttons to select the item code to change.
- Press the timer time **▲** / **▼** buttons to select the desired setting data.

\* For item codes and setting data, refer to the following page.

- Press the **SET** button. (The display stops blinking and remains lit, and setting is completed.)
- Press the **WRENCH** button to return to normal remote controller display.

## [Remote Controller Functions Section]




Fig. 1-1

## <Procedure of CZ-RTC3 / CZ-RTC5A>



Fig. 1-2

- ① Keep pressing the , and buttons simultaneously for 4 or more seconds. The “Maintenance func” screen appears on the LCD display.

Maintenance func	20:30 (THU)
1. Outdoor unit error data	
2. Service contact	
3. RC setting mode	
4. Test run	
↕ Sel.	▶ Page [] Confirm

- ② Press the or button to see each menu. If you wish to see the next screen instantly, press the or button. Select “7. Simple settings” on the LCD display and press the button.

Maintenance func	20:30 (THU)
5. Sensor info.	
6. Servicing check	
7. Simple settings	
8. Detailed settings	
↕ Sel.	◀ ▶ Page [] Confirm

The “Simple settings” screen appears on the LCD display.

Select the “Unit no.” by pressing the or button for changes.

Simple settings		20:30 (THU)
Unit no.	Code no.	Set data
3-1	01	0001
↕ Sel.	▶ Next	

- ③ Select the “Code no.” by pressing the or button. Change the “Code no.” by pressing the or button.

Simple settings		20:30 (THU)
Unit no.	Code no.	Set data
3-1	01	0001
↕ Sel.	▶ Next	

- ④ Select the “Set data” by pressing the or button. Select one of the “Set data” by pressing the or button. Then press the button.

Simple settings		20:30 (THU)
Unit no.	Code no.	Set data
3-1	01	0002
↕ Sel.	[] Confirm	










- ⑤ Select the “Unit no.” by pressing the or button and press the button. The “Exit simple settings and restart?” (Simple setting-end) screen appears on the LCD display. Select “YES” and press the button.

Simple settings		20:30 (THU)
Exit simple settings and restart?		
YES ▶ NO		
↕ Sel.	▶ Next	

5

# 1. Simple Settings Function

## <Procedure of CZ-RTC4>

- ① Press and hold the  and  buttons simultaneously for 4 seconds or longer.
- ② "SETTING", unit No. "1-1" (or "ALL" in the case of group control), item code "01", and settings data "00XX" are displayed blinking on the remote controller LCD display (Fig. 1-3). At this time, the indoor unit fan (or all indoor unit fans in the case of group control) begins operating.
- ③ If group control is in effect, press the  button and select the address (unit No.) of the indoor unit to set. At this time, the fan at the indoor unit begins operating.  
\*If unit No. "ALL" is displayed, the same setting will be made for all indoor units.
- ④ Press the temperature setting  /  buttons to select the item code to change.
- ⑤ Press the timer time  /  buttons to select the desired setting data.  
\*For item codes and setting data, see the following page.
- ⑥ Press the  button. (The display stops blinking and remains lit, and setting is completed.)
- ⑦ Press the  button to return to normal remote controller display.




Fig. 1-3



# 1. Simple Settings Function

## List of Simple Setting Items

Item code	Item	Setting data		
		No.	Description	
01	Filter sign ON time (filter life time)	0000	Not displayed	
		0001	150 hours	
		0002	2,500 hours	
		0003	5,000 hours	
		0004	10,000 hours	
		0005	Use the filter clogging sensor.	
02	Degree of filter fouling	0000	Standard (setting at time of shipping)	
		0001	Highly fouled (Filter sign ON time is reduced to one-half the set time.)	
03	Central control address	0001	Central control address 1	
		0002	Central control address 2	
		0003	Central control address 3	
		}	}	
		0064	Central control address 64	
0099	No central control address set (setting at time of shipping)			
04	Operating mode priority change	0000	Normal (setting at time of shipping)	
		0001	Priority	
05	Fan speed when heating thermostat is OFF		Compressor ON	Compressor OFF
		0000	L 1 min., LL 3min.	LL
		0001	L	LL
		0002	LL	LL
		0004	L 1 min., LL 3min.	L
		0005	L	L
		0006	LL	L
06	Heating intake temperature shift	0000	No shift	
		0001	Shifts intake temperature 1°C down.	
		0002	Shifts intake temperature 2°C down.	
		0003	Shifts intake temperature 3°C down.	
		0004	Shifts intake temperature 4°C down.	
		0005	Shifts intake temperature 5°C down.	
		0006	Shifts intake temperature 6°C down.	
07	Electric heater installation	0000	No heater	
		0001	Heater installed	
08	Humidifying when heater thermostat is OFF	0000	No (setting at time of shipping)	
		0001	Yes	
0d	Permit / prohibit automatic heating / cooling	0000	Permit	
		0001	Prohibit	
0F	Cool-only	0000	Normal	
		0001	Cool only (Set "1" for item code OD.)	

### NOTE

- In order to avoid water leakage and damage to the fan, do not set for humidifying when the thermostat is OFF unless a vaporizing humidifier is used.
- Consider the device purpose and type when changing the settings. Incorrect settings may result in malfunction.
- Do not change any setting data that does not appear in this list.

## Simple setting items

Item code	Item	Description
01	Filter sign ON time setting (filter lifetime)	Changes the indoor unit filter lifetime when a high-performance filter or other optional product is installed.
02	Degree of filter fouling	Reduces the filter sign ON time to 1/2 of the standard time (setting at the time of shipping) for cases when filter fouling is more severe than normal.

## Filter sign ON times for each model

Model data	Model	Filter sign ON time			
		Standard		Long-life	
		Standard	High fouling	Standard	High fouling
0001	4-Way cassette (U1, U2) 4-Way cassette 60 × 60 (Y2)	×	×	2500	1250
0005	Low Silhouette Ducted (F2) Slim Low Static Ducted (M1)	×	×	×	×
0006	High Static Pressure Ducted (E2)	×	×	×	×
0007	Ceiling (T2)	×	×	1500	750
0008	Wall Mounted (K1, K2)	150	75	×	×

Unit: hour

### NOTE

- × indicates that there is no corresponding filter.
- 150 indicates the filter sign ON time that is set at shipment.
- High fouling: Set when 02 is selected for the degree of filter fouling (item code 02).

# 1. Simple Settings Function

Item code	Item	Description
03	Central control address	Set when using a central control device. Used when setting the central control address manually from the remote controller.
04	Operating mode priority change	Note (1)

## NOTE

### (1) Explanation of operation mode priority change

Enabled only in 2WAY System heat-pump models.

#### <Function>

With indoor units that are installed in combination with an outdoor unit model where either heating or cooling operation can be selected, the operating mode of the indoor unit that starts first takes priority. The first indoor unit to operate can select any operating mode. When any mode other than fan mode is selected, then the operating modes that cannot be selected are not displayed on all remote controllers that are subsequently operated. "Operation change control in progress" is displayed, indicating that there are restrictions on the operating modes that can be selected.

#### • Controlling the operating mode from a specific remote controller

- When there are multiple remote controllers in the same refrigerant system, it is possible to set one remote controller as the priority remote controller (the remote controller which is given priority for selecting the operating mode). (If 2 or more remote controllers are set as priority remote controllers, an alarm will occur at the remote controllers, and operation will not be possible.)
- When the priority remote controller is set to the operating mode for control, then all other remote controllers can select only the permitted operating mode, regardless of whether the priority remote controller is operating or stopped.
- When a controlled remote controller is operated, "Operation change control in progress" is displayed.

Set mode at priority remote controller	Modes that can be selected at other remote controllers
Cooling or dry	Cooling, dry, fan
Heating	Heating, fan
Fan	Whichever mode (heating / cooling) is selected first

## NOTE

There are other methods to avoid control in which the mode selected first takes priority.

Methods of remotely controlling the operating mode

- (1) Use the central functions of a central control device.
- (2) Use a remote control relay PCB at the outdoor unit.

When the operating mode at the priority remote controller is changed, the operating modes of other remote controllers change as shown below.

Mode change at priority remote controller		Operating modes at other remote controllers	
Current mode	New mode	Current mode	New mode
Cooling or dry	Heating	Cooling or dry	Heating
		Fan	Fan (not changed)
Heating	Cooling	Heating	Cooling
		Fan	Fan (not changed)
Cooling	Dry	Cooling	Cooling (not changed)
		Dry	Dry (not changed)
Heating	Dry	Heating	Cooling
		Fan	Fan (not changed)
Cooling or dry	Fan	Cooling	Cooling (not changed)
		Dry	Dry (not changed)
		Fan	Fan (not changed)
Heating	Fan	Heating	Heating (not changed)
		Fan	Fan (not changed)






Item code	Item	Description
05	Fan speed setting when heating thermostat is OFF	Changes the fan speed setting when the heating thermostat is OFF.
06	Heating intake temperature shift	Shifts the intake temperature during heating. Can be set when the body thermostat is used.
07	Electric heater installation	Set when cost distribution is performed using an AMY central control system or similar system, and when an optional electric heater is installed. (This is unrelated to control of the electric heater.)
08	Humidifying when heater thermostat is OFF	Normally humidifying does not occur when the thermostat is OFF during heating operation. However, this setting can be changed in order to increase the amount of humidifying. Caution: In order to avoid water leakage and damage to the fan, do not use this setting unless a vaporizing humidifier is used.
0D	Permit / prohibit automatic heating / cooling	This setting can be used to prevent the automatic heating / cooling display on the remote control if the unit configuration permits automatic heating / cooling operation.
0F	Cooling-only	This setting allows a heat pump indoor unit to be operated as a cooling-only unit.

## 2. Detailed Settings Function


- This allows the system address, indoor unit address, and other settings to be made for the individual or group-control indoor unit to which the remote controller used for detailed settings is connected.

When detailed settings mode is engaged, operation stops at the individual or group-control indoor unit where the remote controller used for detailed settings is connected. Simple settings items can also be set at this time.

### <Procedure of CZ-RTC2>

- Press and hold the , **SET** and **CAN CEL** buttons simultaneously for 4 seconds or longer.
- "SET DATA," unit No. "1" (or "ALL" in the case of group control), item code "10," and settings data "00XX" are displayed blinking on the remote controller LCD display (Fig. 2-1).  
At this time, the indoor unit fan (or all indoor unit fans in the case of group control) begins operating.
- If group control is in effect, press the **UNIT** button and select the address (unit No.) of the indoor unit to set. At this time, the fan at the indoor unit begins operating.
- Press the temperature setting  /  buttons to select the item code to change.
- Press the timer time  /  buttons to select the desired setting data.

\* For item codes and setting data, refer to the following page.

- Press the **SET** button. (The display stops blinking and remains lit, and setting is completed.)
- Press the  button to return to normal remote controller display.




Fig. 2-1

<Procedure of CZ-RTC3 / CZ-RTC5A>



Fig. 2-2

- Keep pressing the , and buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.

Maintenance func		20:30 (THU)
1. Outdoor unit error data		
2. Service contact		
3. RC setting mode		
4. Test run		
▼ Sel.	▶ Page [] Confirm	

- Press the or button to see each menu. If you wish to see the next screen instantly, press the or button. Select "8. Detailed settings" on the LCD display and press the button.

Maintenance func		20:30 (THU)
5. Sensor info.		
6. Servicing check		
7. Simple settings		
8. Detailed settings		
◆ Sel.	◀ ▶ Page [] Confirm	

The "Detailed settings" screen appears on the LCD display.

Select the "Unit no." by pressing the or button for changes.

Detailed settings		20:30 (THU)
Unit no.	Code no.	Set data
3-1	10	0001
◆ Sel.	▶ Next	

- Select the "Code no." by pressing the or button. Change the "Code no." by pressing the or button (or keeping it pressed).

Detailed settings		20:30 (THU)
Unit no.	Code no.	Set data
3-1	10	0001
◆ Sel.	▶ Next	

- Select the "Set data" by pressing the or button. Select one of the "Set data" by pressing the or button. Then press the button.











Detailed settings		20:30 (THU)
Unit no.	Code no.	Set data
3-1	10	0001
◆ Sel.	[] Confirm	

- Select the "Unit no." by pressing the or button and press the button. The "Exit detailed settings and restart?" (Detailed setting-end) screen appears on the LCD display. Select "YES" and press the button.

Detailed settings		20:30 (THU)
Exit detailed settings and restart?		
YES ▶ NO		
◆ Sel.	▶ Next	

## 2. Detailed Settings Function

### <Procedure of CZ-RTC4>

- ① Press and hold the ,  and  buttons simultaneously for 4 seconds or longer.
- ② "SETTING", unit No. "1-1", item code "10", and settings data "00XX" are displayed blinking on the remote controller LCD display (Fig. 2-3). At this time, the indoor unit fan begins operating.
- ③ If group control is in effect, press the  button and select the address (unit No.) of the indoor unit to set. At this time, the fan at the indoor unit begins operating.  
\* If unit No. "ALL" is displayed, the same setting will be made for all indoor units.
- ④ Press the temperature setting  /  buttons to select the item code to change.
- ⑤ Press the timer time  /  buttons to select the desired setting data.  
\* For item codes and setting data, see the following page.
- ⑥ Press the  button. (The display stops blinking and remains lit, and setting is completed.)
- ⑦ Press the  button to return to normal remote controller display.





Fig. 2-3

## 2. Detailed Settings Function


- Setting the Flap Separately (When setting the CZ-RTC2)
  - 1) The 4-air outlet flap can be adjusted separately during operation. When not adjusted separately, all flaps operate in the same manner.



### <Procedure of CZ-RTC2>

Stop the system before performing these steps.

- 1 Press and hold the , **SET** and **CAN/CEL** buttons simultaneously for 4 seconds or longer.
- 2 If group control is in effect, press the **UNIT** button and select the address (unit No.) of the indoor unit to set. At this time, the fan at the indoor unit begins operating.
- 3 “**SETTING**,” unit No. “**- -**” (or “**ALL**” in the case of group control), item code “**XX**,” and settings data “**YYYY**” are displayed blinking on the remote controller LCD display.
- 4 Designate the item code “**XX**” by adjusting the Temperature Setting / buttons.



- 5 Press the timer time / buttons to select the desired setting data.




Fig. 2-4

- \* Setting data “**YYYY**” (refer to Fig.2-4)

Setting data	Flap position during operation
<b>0000</b>	Without separate setting
<b>0001</b>	Swing
<b>0002</b>	Move to position <b>1</b> and stay
<b>0003</b>	Move to position <b>2</b> and stay
<b>0004</b>	Move to position <b>3</b> and stay
<b>0005</b>	Move to position <b>4</b> and stay
<b>0006</b>	Move to position <b>5</b> and stay


When the flap position is set to **4** or **5** and the unit is in the cooling or dry mode, the flap position is moved to **3** and the operation is started. (refer to Fig.2-4)

### NOTE

The flap swings during the operation under "Setting the Flap Separately".

At this time, the unselected flaps are moved to the position **1**. (refer to Fig.2-4)


- 6 Press the **SET** button.  
(The display stops blinking and remains lit, and setting is completed.)  
If you wish to change the selected indoor unit, follow the step 2 .
- 7 Press the button to return to normal remote controller display.





When setting the flap for each air outlet individually according to the room condition. (from Operating Instructions)

### <Procedure of CZ-RTC3 / CZ-RTC5A>




① Display the menu screen.



- To return to the previous screen  
Press
- To return to the top screen  
Press 2 times.


② Select "3. Lock indiv. flap"



③ Select the indoor unit to set.




e.g. 1-1 → 1-2 to 1-8



④ Select the air outlet.



- The air outlet No. changes according to the installation direction. Check by actual operation.




⑤ Select the flap direction.




(Press 2 times to finish.)

- Although is also displayed in Cool and Dry mode, the actual direction is .




\* For types other than the 4-Way cassette type, the following display appears and this function cannot be used.




**<Procedure of CZ-RTC4>**

**Stop the system before performing these steps.**

- ① Press and hold the , and buttons simultaneously for 4 seconds or longer.
- ② If group control is in effect, press the button to set. At this time, the fan at the indoor unit begins and select the address (unit No.) of the indoor unit operating.
- ③ Designate the item code “**XX**” by adjusting the Temperature Setting / buttons.



- ④ Press the timer time buttons to select the desired setting data.




\* Setting data “**YYYY**”

Setting data	Flap position during operation
<b>0000</b>	Without separate setting
<b>0001</b>	Swing
<b>0002</b>	Move to position <b>1</b> and stay
<b>0003</b>	Move to position <b>2</b> and stay
<b>0004</b>	Move to position <b>3</b> and stay
<b>0005</b>	Move to position <b>4</b> and stay
<b>0006</b>	Move to position <b>5</b> and stay

**NOTE**

The flap swings during the operation under “Setting the Flap Separately”.  
 At this time, the unselected flaps are moved to the position **1**.

- ⑤ Press the button.  
 (The display stops blinking and remains lit, and setting is completed.)  
 If you wish to change the selected indoor unit, follow the step ②.
- ⑥ Press the button to return to normal remote controller display.



### List of Detailed Setting Items

Item code	Item	Setting data					
		No.	Description	No.	Description	No.	Description
10	Type	0001	4-Way Cassette (60×60) (U1, U2, Y2)	0002	2-Way Cassette (L1)	0003	1-Way Cassette (D1)
		0005	Low Silhouette Ducted (F2) Slim Low Static Ducted (M1)	0006	High Static Pressure Ducted (E1,E2)	0007	Ceiling (T2)
		0008	Wall mounted (K1, K2)	0010	Floor Standing (P1)	0011	Concealed Floor Standing (R1)
		0017	Fresh Air Intake Duct (H1) For S-140MH1H5	0026	Fresh Air Intake Duct (H1) For S-224MH1H5 and S-280MH1H5 High Static Pressure Ducted (E2) Fresh Air Intake Mode		
		0037	Slim Type Ducted (Z1)				
11	Indoor unit capacity	0038	15 (Type 15)	0001	22 (Type 22)	0003	28 (Type 28)
		0005	36 (Type 36)	0007	45 (Type 45)	0009	56 (Type 56)
		0010	63 (Type 60)	0011	71 (Type 73) For S-71MP1E5 and S-71MR1E5	0012	80 (Type 73) Except S-71MP1E5 and S-71MR1E5
		0013	90 (Type 90)	0015	112 (Type 106)	0017	140 (Type 140)
		0018	160 (Type 160)	0020	180 (Type 180)	0021	224 (Type 224)
		0023	280 (Type 280)				
12	System address	0001	Unit No. 1				
		0002	Unit No. 2				
		0003	Unit No. 3				
		}	}				
		0030	Unit No. 30				
		0099	Not set				
13	Indoor unit address	0001	Unit No. 1				
		0002	Unit No. 2				
		0003	Unit No. 3				
		}	}				
		0064	Unit No. 64				
		0099	Not set				
14	Group control address	0000	Individual (1:1 = Indoor unit with no group wiring)				
		0001	Main unit (One of the group-control indoor units)				
		0002	Sub unit (All group-control indoor units except for main unit)				
		0099	Not set				
17	Cooling intake temperature shift	-010	Shifts intake temperature 10°C down.				
		-009	Shifts intake temperature 9°C down.				
		}	}				
		-001	Shifts intake temperature 1°C down.				
		0000	No intake temperature shift				
		0001	Shifts intake temperature 1°C up.				
		}	}				
		0009	Shifts intake temperature 9°C up.				
0010	Shifts intake temperature 10°C up.						
18	Automatic stop time after operation start  *Can be set in 5-minute units.	0000	Function disabled				
		0001	Stops automatically 5 minutes after operation starts.				
		0002	Stops automatically 10 minutes after operation starts.				
		}	}				
		0123	Stops automatically 615 minutes after operation starts.				
		0124	Stops automatically 620 minutes after operation starts.				
0125	Stops automatically 625 minutes after operation starts.						

## 2. Detailed Settings Function


Item code	Item	Setting data		
		No.	Description	
<b>1b</b> (1B)	Forced thermostat ON time	0000	5 minutes	
		0001	4 minutes	
<b>1c</b>	Cooling discharge temperature shift	-010	Shifts discharge temperature setting 10°C down	
		-009	Shifts discharge temperature setting 9°C down	
		-008	Shifts discharge temperature setting 8°C down	
		}	}	
		0010	Shifts discharge temperature setting 10°C up	
<b>1d</b>	Heating discharge temperature shift	-010	Shifts discharge temperature setting 10°C down	
		-009	Shifts discharge temperature setting 9°C down	
		-008	Shifts discharge temperature setting 8°C down	
		}	}	
		0010	Shifts discharge temperature setting 10°C up	
<b>1e</b>	Temperature shift for cooling / heating change in auto heat / cool mode	0001	±1°C	
		0002	±2°C	
		0003	±3°C	
		}	}	
		0007	±7°C	
<b>1f</b> (Upper limit) <b>20</b> (Lower limit)	Change to remote control temperature setting range	Cooling	0018	18°C (Lower limit at shipment)
			0019	19°C
			}	}
			0029	29°C
			0030	30°C (Upper limit at shipment)
			Heating	0016
		0017		17°C
		}		}
		0029		29°C
		0030		30°C (Upper limit at shipment)
		Drying		0018
			0019	19°C
}	}			
0029	29°C			
0030	30°C (Upper limit at shipment)			
Auto heat / cool	0017		17°C (Lower limit at shipment)	
	0018	18°C		
	}	}		
	0026	26°C		
	0027	27°C (Upper limit at shipment)		
	<b>29</b>	Humidifier operation	0000	Normal
0001			Ignore heat exchanger temperature conditions.	
<b>2a</b>	Filter (CN70) input switching	0000	Filter input (differential pressure switch input)	
		0001	Alarm input (for trouble input about air cleaner or similar device)	
		0002	Humidifier input (Operates linked with drain pump when humidifier is ON.)	
<b>2c</b>	Indoor unit electronic control valve	0000	Present (Setting at shipment)	
		0002	None	
<b>2e</b>	T10 terminal switching	0000	Normal (Used as optional relay PCB or JEMA standard HA terminal.)	
		0001	Used for OFF reminder	
		0002	Fire prevention input	

Item code	Item	Setting data				
		No.	Description			
2F	Automatic drain pump operation	0000	No forced operation			
		0001	Forced operation for 1 minute			
		{	{			
		0060	Continuous operation			
31	Ventilation fan operation	0000	None			
		0001	Ventilation fan operated by remote controller.			
32	Wired remote controller sensor	0000	Not used. (Body sensor is used.)			
		0001	Remote control sensor is used.			
34	"Operation change control in progress" display	0000	Normal (displayed)			
		0001	Not displayed			
35	OFF reminder function for when weekly timer is used	0000	None			
		0001	Only stop time setting is enabled.			
3A	Discharge temperature control	0000	Discharge temperature control OFF			
		0001	Discharge temperature control ON			
3C	Heat exchanger temperature for cold air discharge (Heat exchanger control point for control to prevent cold air)	0013	Control temperature 13°C			
		0014	Control temperature 14°C			
		{	{			
		0025	Control temperature 25°C			
		0026	Control temperature 26°C			
3d	Fan output switching	0000	Output linked with fan. (ON when indoor unit fan is operating.)			
		0001	Fan mode operation output			
3E	Drain pump delayed stop time	0000	No delayed stop			
		0001	1 second delayed stop	Except Indoor unit	1 minute delayed stop	Indoor unit
		0002	2 seconds delayed stop		2 minutes delayed stop	
		{	{			
		0058	58 seconds delayed stop	Type U1, U2, Y2, F2, T2, E2	58 minutes delayed stop	Type U1, U2, Y2, F2, T2, E2
		0059	59 seconds delayed stop		59 minutes delayed stop	
		0060	60 seconds delayed stop		60 minutes delayed stop	
40	Humidifier setting	0000	Humidifier output OFF. Drain pump stopped.			
		0001	Humidifier output ON. Drain pump operates.			
		0002	Humidifier output ON. Drain pump operates for 1 minute when total humidifier operating time reaches 60 minutes.			
		0003	Humidifier output ON. Drain pump stopped.			
45	Flap operation mode	0000	Standard setting			
		0001	Draft reduction mode (Flap lower-limit position is shifted upwards.)			
46	Flap swing mode	0000	Smudging reduction mode (Flap swing upper-limit position is shifted downwards.)			
		0001	Normal mode			
		0002	Draft reduction mode (Flap swing lower-limit position is upwards.)			

Item code	Item	Setting data			
		No.	Description		
5d	Fan tap setting (Fan tap change in order to prevent drop in air discharge caused by filter installation)		DC fan tap operating mode	Purpose	
		0000	Standard	Standard (setting at shipment)	
		0001	High ceiling use	High ceiling setting 1 (with standard panel)	
			For low static-pressure filter	Ultra long-life filter, oil guard panel, ammonia deodorizing filter, optical regenerative deodorizing filter	
		0003	High ceiling use	High ceiling setting 2 (with standard panel)	
			For low static-pressure filter	(Antibacterial) high-performance filter (90%) (Antibacterial) high-performance filter (65%)	
Air-cleaning unit, air-cleaning unit + optical regenerative deodorizing filter, deodorant (activated charcoal) filter					
	For air-blocking material	For 3-way discharge, when discharge duct is connected			
0006	For air-blocking material	For 2-way discharge			
5E	Humidifier ON time (ON time per 60 seconds)	0000	No humidifier output		
		0001	1 second		
		0002	2 seconds		
		}	}		
		0058	58 seconds		
		0059	59 seconds		
		0060	Continuously ON		
60	Timer function change prohibit	0000	Function disabled		
		0001	Function enabled		
62	Smudging control	0000	No smudging control		
8F	Waiting time for dew condensation prevention control	0000	Without dew condensation prevention control		
		0001	Dew condensation prevention control after 10 minutes		
		0002	Dew condensation prevention control after 20 minutes		
		}	}		
		0010	Dew condensation prevention control after 100 minutes		
		0011	Dew condensation prevention control after 110 minutes		
		0012	Dew condensation prevention control after 120 minutes		
90	Setting the Flap Separately *Only for 4-Way Cassette type	0000			
		0001			
		0002			
		0003			
		0004			
		0005			
		0006			
91	Setting the Flap Separately *Only for 4-Way Cassette type	0004	Air outlet flap (adjustment for up-down airflow direction)		
		0005			
92	Setting the Flap Separately *Only for 4-Way Cassette type	0000	Setting data	Flap position during operation	When the flap position is set to [4] or [5] and the unit is in the cooling or dry mode, the flap position is moved to [3] and the operation is started.  <b>NOTE</b> The flap swings during the operation under "Setting the Flap Separately". At this time, the unselected flaps are moved to the position [1].
		0000	Without separate setting		
		0001	Swing		
		0002	Move to position [1] and stay		
		0003	Move to position [2] and stay		
		0004	Move to position [3] and stay		
93	Setting the Flap Separately *Only for 4-Way Cassette type	0005	Move to position [4] and stay		
		0006	Move to position [5] and stay		

Item code	Item	Setting data	
		No.	Description
<b>9F</b>	With or without nanoe™ X function, Operation setting	0000	Without nanoe™ X function
		0001	With nanoe™ X function (Not operational if R/C with nanoe™ X not connected)
		0002	With nanoe™ X function (Operational even if R/C with nanoe™ X not connected)
<b>F8</b>	Internal cleaning dry times (when humidity is over 70%)	0000	Without fan operation
		0001	1 minute
		0002	2 minute
		}	}
		0118	118 minute
		0119	119 minute
		0120	120 minute
<b>F9</b>	Internal cleaning dry times (when humidity is less than 70%)	0000	Without fan operation
		0001	1 minute
		0002	2 minute
		}	}
		0118	118 minute
		0119	119 minute
		0120	120 minute

Item code	Item	Description
10	Unit type	Set when the indoor unit EEPROM memory is replaced during servicing.
11	Indoor unit capacity	
12	System (outdoor unit) address	These are not set at the time of shipping from the factory. These must be set after installation if automatic address setting is not performed.
13	Indoor unit address	
14	Group address	
17	Cooling intake temperature shift	Shifts the intake temperature during cooling and dry operation. (Enabled only when the body thermostat is used.) Increase this value when it is difficult to turn the thermostat ON.
18	Automatic stop time after operation start	The time at which an indoor unit is automatically stopped after operation starts can be set in increments of 5 minutes.
1E	Temperature shift for cooling / heating change in "auto heat / cool" mode	"Auto heat / cool" selects the operating mode automatically based on the difference between the room temperature and the temperature set on the remote controller. This setting establishes a shift temperature for the heating / cooling temperature setting relative to the remote controller temperature setting.





Item code	Item	Description	
1F (Upper limit) 20 (Lower limit)	Change to the remote control temperature setting range	This setting changes the temperature range (upper limit and lower limit) which is set from the remote controller or central control device. The set upper limit must be greater than or equal to the lower limit. If the temperature setting is to be a single point, set the upper limit and lower limit to the same temperature.	
21 (Upper limit) 22 (Lower limit)			Cooling
23 (Upper limit) 24 (Lower limit)			Heating
25 (Upper limit) 26 (Lower limit)			Drying
29	Humidifier operation which ignores the heat exchanger temperature	During heating operation, the humidifier operates when the heat exchanger temperature is suitable for humidifying. This setting is used to ignore this condition for humidifier operation and operate the humidifier more.	
2A	Filter input switching	This setting switches the filter input according to the purpose of use.	
2C	Indoor unit electronic control valve	This setting indicates whether or not an indoor unit electronic control valve is present. At the time of shipping, this setting is set according to the conditions of the indoor unit.	
2E	T10 terminal input switching	Ordinarily, the T10 terminal is used as the HA terminal at the time of shipping. However, this setting is used when the T10 terminal is used for OFF reminder or for fire prevention input.	
31	Ventilation fan operation from remote controller	It is possible to install a total heat exchanger and ventilation fan in the system, which can be started and stopped by the wired remote controller. The ventilation fan can operate linked with the start and stop of the indoor unit, or can be operated even when the indoor unit is stopped. Use a ventilation fan that can accept the no-voltage A contact as the external input signal. In the case of group control, the fans are operated together. They cannot be operated individually.	
32	Switching to remote controller sensor	This setting is used to switch from the body sensor to the remote controller sensor. Check that "remote controller sensor" is displayed. Do not use this setting with models that do not include a remote controller sensor. Do not use this setting if both the body sensor and remote sensor are used.	
34	ON / OFF of "Operation change control in progress" display	In a MULTI system with multiple remote controllers, switching between heating and cooling is restricted, and "Operation change control in progress" is displayed. This setting is used to prevent this display from appearing. Refer to the item concerned with operating mode priorities.	
35	OFF reminder function for weekly timer	This setting switches the operation when the weekly timer is connected to the remote controller. This can be used to prevent cases in which the unit is accidentally left ON. There is no change when this setting is ON, however it is necessary to set the weekly timer ON time.	

(Continued)

(Continued from previous page)

Item code	Item	Description
3C	Heat exchanger temperature for cold air discharge	The heat exchanger temperature control point for prevention of cold air discharge during heating operation can be changed.
3d	Fan output switching	The indoor unit PCB optional output for the fan can be switched according to the purpose of use.
3E	Drain pump delayed stop time	The drain pump stops after the set time delay after cooling operation stops.
40	Humidifier drain pump setting	This specifies the humidifier and drain pump setting.
45	DC flap operation mode	Changes flap operation to draft reduction mode.
46	DC flap swing mode	Selects the swing operation mode for the flap.
5d	DC fan tap setting	Sets the DC fan tap according to the purpose of use. Change the settings data at the same time.
5E	Humidifier ON time	Sets the humidifier output ON time for when the humidifier is operating. ON / OFF control is performed during humidifier operation. This setting therefore sets the ON time per 60-second interval.
5F	Stop at time set for OFF timer after operation starts	This setting enables a function that stops operation when the amount of time set for the OFF timer has passed after remote controller operation was started.
60	Timer function change prohibit	This function prohibits changes from being made to the remote controller time setting.
62	Smudging control	Smudging control is disabled when 0000 is set.


## 2. Detailed Settings Function

### Selecting the DC fan motor tap (when setting with the remote controller)

#### <Procedure of CZ-RTC2>

Stop the system before performing these steps.

- ① Press and hold the , **SET** and **CAN CEL** buttons simultaneously for 4 seconds or longer.
- ② If group control is in effect, press the **UNIT** button and select the address (unit No.) of the indoor unit to set. At this time, the fan at the indoor unit begins operating.
- ③ Use the temperature setting buttons to select item code "5d."
- ④ Press the timer time / buttons to select the desired setting data.  
\* For item codes and setting data, see Table 2-1 – Table 2-3.
- ⑤ Press the **SET** button. (The display stops blinking and remains lit, and setting is completed.)  
To change the selected indoor unit, go to step ②.
- ⑥ Press the button to return to normal remote controller display.



\* Failure to make this setting may result in decreased airflow and condensation.

**Table 2-1 Table of DC Fan Motor Tap Settings (4-Way Cassette type) (Type U1)**

Setting No.	Remote controller setting data	Contents & optional parts name
(3)	0000	Standard (setting at time of shipping)
	0003	Air-blocking material (for 3-way air discharge)
	0003	Air-blocking material (when a discharge duct is connected)
(6)	0006	Air-blocking material (for 2-way air discharge)

**Table 2-2 Table of DC Fan Motor Tap Settings (Ceiling type)**

Setting No.	Remote controller setting data	Purpose of use, names of accessories
(1)	0001	Standard (setting at time of shipping)
		High ceiling setting
		Super long-life filter
		Ammonia deodorant filter (65% by JIS colorimetric method)
(3)	0003	Optical regeneration deodorant filter
		High performance filter (65% by JIS colorimetric method)
		Deodorant filter (65% by JIS colorimetric method)

**Table 2-3 Table of DC Fan Motor Tap Settings (4-Way Cassette type) (Type U2)**

Setting No.	Remote controller setting data Item code 5d	Contents & optional parts name
(1)	0001	Air-flow blocking kit (for 3-way air flow)*1
		Air-flow blocking kit (when a duct is connected.)
		High-ceiling setting 1*1
(3)	0003	High-ceiling setting 2*1
(6)	0006	Air-flow blocking kit (for 2-way air flow)*1

\* When using optional parts in different setting No. in combination with multiple units, conform it to the larger setting No.


\*1 Ceiling height (m)

Indoor unit type	22, 28, 36, 45, 56	60, 73, 90	106, 140, 160
Standard (factory setting)	2.7	3.0	3.6
High-ceiling setting 1	3.2	3.3	4.3
High-ceiling setting 2	3.5	3.6	5.0
Air-flow blocking kit (for 3-way air flow)	3.8	3.8	4.7
Air-flow blocking kit (for 2-way air flow)	4.2	4.2	5.0


### <Procedure of CZ-RTC3 / CZ-RTC5A>

Stop the system before performing these steps.

- Keep pressing the , and buttons simultaneously for 4 or more seconds. The “Maintenance func” screen appears on the LCD display.




- Press the or button to see each menu. If you wish to see the next screen instantly, press the or button. Select “8. Detailed settings” on the LCD display and press the button.




The “Detailed settings” screen appears on the LCD display.

- Select the “Unit no.” by pressing the or button for changes.




- Select the “Code no.” by pressing the or button. Change the “Code no.” to “5D” by pressing the or button (or keeping it pressed).




- Select the “Set data” by pressing the or button.

Select one of the “Set data” in “Table for DC Fan Motor Tap Setting (Table 2-1 – Table 2-3)” by pressing the or button. Then press the button.











- Press the button. The “Exit detailed settings and restart?” (Detailed setting-end) screen appears on the LCD display. Select “YES” and press the button.





If you wish to change the selected indoor unit, follow the step ②.


### <Procedure of CZ-RTC4>

Stop the system before performing these steps.

- ① Press and hold the ,  and  buttons simultaneously for 4 seconds or longer.
- ② If group control is in effect, press the  button to set. At this time, the fan at the indoor unit begins and select the address (unit No.) of the indoor unit operating.
- ③ Designate the item code **5d** by adjusting the Temperature Setting  /  buttons.
- ④ Press the timer time  /  buttons to select the desired setting data.

\* For item codes and setting data, see Table 2-1 – Table 2-3.

- ⑤ Press the  button.  
(The display stops blinking and remains lit, and setting is completed.)  
If you wish to change the selected indoor unit, follow the step ②.
- ⑥ Press the  button to return to normal remote controller display.



\* Failure to make this setting may result in decreased airflow and condensation.

## Selecting the DC fan motor tap (when setting from the PCB)

### ● 4-Way Cassette type (Type U1)

<Procedure> Stop the system before performing these steps.

- ① Open the electrical component box cover, then check the indoor unit control PCB. (Fig. 2-5)
- ② Connect the jumper connector (2P: yellow) which was supplied with the accessory to the correct connector pin on the indoor unit control PCB according to the setting number which was confirmed in Table for DC Fan Motor Tap Settings.

Setting No. (3) :

Then connect the jumper connector to the connector pin TP3 (2P: yellow) on the indoor unit control PCB.

Setting No. (6) :

Then connect the jumper connector to the connector pin TP6 (2P: white) on the indoor unit control PCB.

### ● Ceiling type

<Procedure> Stop the system before performing these steps.

- ① Open the electrical component box cover, then check the indoor unit control PCB. (Fig. 2-6)
- ② Connect the jumper connector (2P: yellow) which was supplied with the accessory to the correct connector pin on the indoor unit control PCB according to the setting number which was confirmed in Table 2-2 (Table of DC Fan Motor Tap Settings).
  - If the setting No. is (1), then connect the jumper connector to the connector pin TP1 (2P: red) on the indoor unit control PCB.
  - If the setting No. is (3), then connect the jumper connector to the connector pin TP3 (2P: yellow) on the indoor unit control PCB.




Fig. 2-5

### ● 4-Way Cassette type (Type U2)

<Procedure> Stop the system before performing these steps.

- ① Open the electrical component box cover, then check the indoor unit control PCB. (Fig. 2-6)
- ② Change the DIP switch on the indoor unit control PCB in accordance with the setting number which was confirmed in Table for DC Fan Motor Tap Settings.

Setting No.	DIP switch
(1)	
(3)	
(6)	




Fig. 2-6


## EXTERNAL STATIC PRESSURE SETTING

### • Low Silhouette Ducted (S-15~160MF2E5A / S-15~160MF2E5A8)

Choose one of the following methods from “a”, “b”, “c” or “d” as shown in the flow chart (within the dotted lines) and then make the setting accordingly.

- a. No setting modification..... : Use-as-is at shipment (there are cases in which the setting may differ from the shipment setting when reset after once setting the external static pressure.)
- b. Manual setting (set with the PC board)..... : For high static pressure. Switching method with the short-circuit connector.
- c. Manual setting (set with the wired remote controller) ..... : Low static pressure ~ high static pressure
- d. Auto airflow volume setting (set on the wired remote controller) .... : Air outlet volume is automatically adjusted to the rated airflow volume with the auto airflow control drive.

### Flow of External Static Pressure



5

### NOTE

- (1) Check the following items before performing the setting-check operations or auto airflow volume operations.
  - 1) Check to make sure that the electrical wiring and ducting have been completed. Activate the stand-by mode. In particular, make sure that the closed damper located in the middle of the duct is open, if installed. Also, make sure that air filters have been installed inside the air inlet duct.  
Check to make sure air is not leaking from the joints.
  - 2) If multiple air outlets and air inlets are included, adjust the airflow volume ratio of all of them until they meet the design airflow ratio.
  - 3) Make sure the address setting has been completed.
- (2) The operation check will be completed in approximately three minutes if the settings have been made correctly. The settings will be modified if they are out of the range of use (maximum 30 minutes). If this is not completed within 31 minutes, check whether the air speed is set to “H” or not.

## 2. Detailed Settings Function

- (3) Refer to Table 2-5, 2-6, 2-7 and Fig. 2-8 for details on the relationship between the value of item code “b0” and the external static pressure.
- (4) When set in group control (connecting multiple indoor units with one wired remote controller), set each indoor unit to item code “b0”. When amending the setting after selecting [ b. Manual setting] (due to airflow path changes, etc.), it is necessary to cancel [b. Manual setting] (disconnect short-circuit connector). When [b. Manual setting] has not been cancelled, [c. Manual setting] and [d. Auto airflow volume setting] will be activated if selected, but [b. Manual setting] takes precedence when the power is switched back on after power outages, etc.
- (5) If this is not completed within 8 minutes, check the drive mode, air speed and air inlet temperature.
- (6) When set in group control (connecting multiple indoor units with one wired remote controller), the test run operations display will disappear once the external static pressure setting check or auto airflow volume control operation check have been completed for the main unit. Decisions on sub-unit complete are not possible. The test run operation display will disappear after one hour even if the external static pressure setting check or auto airflow volume control operation check have not been completed.

### ⚠ CAUTION

- **Be sure to check that the external static pressure is within the range for use and then make the setting. Failure to observe this may result in insufficient airflow or water leakages. Refer to Fig. 2-8 for the external static pressure setting range.**
- **There are cases in which automatic variable dampers and other mounted items may trigger the P12 alarm on systems that modify the static pressure of outdoor units when the auto airflow volume control operations or setting check operations are carried out if high static pressure in the outdoor unit is lowered. In this event, lower the dampers, etc., so that the static pressure in the outdoor unit reaches its lowest level, and then carry out the auto airflow volume control operations or setting check operations.**
- **Be sure to set the [External Static Pressure Setting] once again after amending the airflow path for the duct or air outlet after setting the external static pressure.**
- **Set the air inlet temperature within the range for use. The auto airflow volume control will not function if the air inlet temperature is over 45°C or not in the fan mode.**


#### 1-1. How to Set on PC Board

1. Turn off the power breaker to halt the supply of electricity to the PC board.
2. Open the lid of electrical equipment box and check where the short-circuit pin on the indoor unit control PC board is located (Fig. 2-7)
3. Short circuit the applicable short-circuit pin in accordance with the selected short-circuit pin connected (Table 2-4).  
150 Pa : TP3 (2P: yellow) short-circuit  
140 Pa : TP1 (2P: red) short-circuit

\* Use the short-circuit connector (2P: yellow) supplied.

Table 2-4 Selection of connected short-circuit pins

External static pressure at the time of rated airflow volume	Short-circuit pin
Unusable	TP6 (2P: white)
150 Pa	TP3 (2P: yellow)
140 Pa	TP1 (2P: red)



Indoor Unit control PC board

Fig. 2-7



## 1-2. Operating the Timer Remote Controller (CZ-RTC2)

### 1-2-1. Setting Item Code “b0”

- Press and hold down the , and buttons simultaneously for 4 or more seconds.  
( , the Unit No., Item Code and Detailed Data will blink on the remote controller's LCD display.)
- The indoor unit numbers in the group control will be sequentially displayed whenever the Unit Select button is pressed .  
Only the fan motor for the selected indoor unit will operate during this.
- Specify the “b0” item code by pressing the / buttons for the temperature setting buttons and confirm the values.  
(“-001” set at shipment )
- Press the / buttons for the time to amend the values for the set data.  
Refer to table 2-5 and Fig. 2-8 and select a value between “0001” and “0015”.  
Select “-002” if the auto airflow volume setting is activated.
- Press the button.  
The display will stop blinking and remain illuminated.
- Press the button. The fan motor will stop operating and the LCD display will return to the normal stop mode.

### 1-2-2. Auto Airflow Volume Control Operations and External Static Pressure Setting-Check Operation

- Press and hold down the button for 4 or more seconds. “TEST” will be displayed on the remote controller's LCD display.
- Press the button to commence the test run.  
[Test Run] will be displayed on the remote controller's LCD display.
- Select the fan mode and set it to “H” by pressing the button.


#### CAUTION

Auto airflow volume control operations and external static pressure setting-check operations will not be performed unless [H] has been selected for the fan mode.


- The fan motor will be activated and auto airflow volume control operations or external static pressure setting-check operations will commence.  
The power of the airflow will change while these operations are in progress.  
The external static pressure setting-check operations and auto airflow volume control operations will be completed in about 3 to 30 minutes.  
The “TEST” display will be extinguished from the remote controller's LCD display.
- Press the button to halt the test run.

Table 2-5 Setting the external static pressure

Indoor unit		Item code
15, 22, 28, 36, 45, 56, 60, 73, 90	106, 140, 160	b0
External static pressure of the rated air flow volume (Pa)		
150	150	00 15
140	140	00 14
130	130	00 13
120	120	00 12
100	110	00 11
70	100	00 08
60	70	00 06
50	50	00 05
30	30	00 03
10	10	00 01
No auto airflow volume setting		-001
Auto airflow volume setting		-002



\* Failure to set this parameter may result in decreased airflow and condensation.




### 1-3. Operating the High-spec Wired Remote Controller (CZ-RTC3 / CZ-RTC5A)




#### How to set the external static pressure

- Keep pressing the , and buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.




- Press the or button to see each menu. If you wish to see the next screen instantly, press the or button. Select "8. Detailed settings" on the LCD display and press the button.




The "Detailed settings" screen appears on the LCD display.

Select the "Unit no." by pressing the or button for changes.



- Select the "Code no." by pressing the or button. Change the "Code no." to "B0" by pressing the or button (or keeping it pressed).



- Select the "Set data" by pressing the or button. Select one of the "Set data" among "0001" – "0015" according to the desired external static pressure setting by pressing the or button. Then press the button. (See the table below.)


#### When setting to auto airflow volume control:

Select the setting data to "-002". Then press the button.

**Table 2-6 Setting the external static pressure**


Indoor unit		Item code
15, 22, 28, 36, 45, 56, 60, 73, 90	106, 140, 160	<b>B0</b>
External static pressure of the rated air flow volume (Pa)		
150	150	<b>0015</b>
140	140	<b>0014</b>
130	130	<b>0013</b>
120	120	<b>0012</b>
100	110	<b>0011</b>
70	100	<b>0008</b>
60	70	<b>0006</b>
50	50	<b>0005</b>
30	30	<b>0003</b>
10	10	<b>0001</b>
No auto airflow volume setting		<b>-001</b>
Auto airflow volume setting		<b>-002</b>

- Select the "Unit no." by pressing the or button and press the button. The "Exit detailed settings and restart?" (Detailed setting-end) screen appears on the LCD display. Select "YES" and press the button. When the setting is completed, perform the test run for the external static pressure setting described in "Auto External Static Pressure Setting Operation".




## Auto External Static Pressure Setting Operation


6. Keep pressing the , and buttons simultaneously for 4 or more seconds. The “Maintenance func” screen appears on the LCD display.




7. Press the or button to see each menu. If you wish to see the next screen instantly, press the or button. Select “4. Test run” on the LCD display and press the button.




The “Test run” screen appears on the LCD display.




- Change the display from OFF to ON by pressing the or button. Then press the button.




The “Maintenance func” screen appears on the LCD display.




8. Press the button. “TEST” will be displayed on the LCD display.




9. Press the button. Test run will be started. Test run setting mode screen appears on the LCD display.



10. Set the operation mode to “” and fan speed mode to “” by pressing the or button or or button. Then press the button.




The fan motor will be activated, the auto external static pressure setting operation and setting-check operation will be performed for about 3 to 30 minutes. The fan speed will change automatically while these operations are in progress. When these operations completed, “TEST” will be disappeared from the LCD display.



**NOTE:**

The auto external static pressure setting operation and setting-check operation will not be performed unless “ (MODE FAN)” and “ (FAN SPEED)” have been selected.

11. Press the button. The LCD display will be returned to the initial screen.



**NOTE:**

Failure to set this parameter may result in decreased airflow and condensation.

## 1-4. Operating the Timer Remote Controller (CZ-RTC4)

### 1-4-1. Setting Item Code "b0"

- Press and hold down the , and buttons simultaneously for 4 or more seconds.  
( **SETTING** , the Unit No., Item Code and Detailed Data will blink on the LCD display.)
- The indoor unit numbers in the group control will be sequentially displayed whenever the Unit Select button is pressed .  
Only the fan motor for the selected indoor unit will operate during this time.
- Specify the "b0" item code by pressing the / buttons for the temperature setting buttons and confirm the values.  
( " - 001 " set at shipment )
- Press the / buttons for the time to amend the values for the set data.  
Refer to Table 2-7 and Fig. 2-8 and select a value between "0001" and "0015".  
Select " - 002 " if the auto airflow volume setting is activated.
- Press the button.  
The display will stop blinking and remain illuminated.
- Press the button. The fan motor will stop operating and the LCD display will return to the normal stop mode.

### 1-4-2. Auto Airflow Volume Control Operations and External Static Pressure Setting-Check Operation

- Press and hold down the button for 4 or more seconds.  
"TEST" will be displayed on the LCD display.
- Press the button to start the test run.
- Select the operation mode (Fan) by pressing the (Mode select) button.  
Then select the fan speed by pressing the (Fan speed) button.


**NOTE**

Auto airflow volume control operations and external static pressure setting-check operations will not be performed unless the above settings are made.


- The fan motor will be activated and auto airflow volume control operations or external static pressure setting-check operations will be started.  
The power of the airflow will change while these operations are in progress.  
The external static pressure setting-check operations and auto airflow volume control operations will be completed in about 3 to 30 minutes.  
"TEST" display will be disappeared from the LCD display.
- Press the button to halt the test run.

Table 2-7 Setting the external static pressure

Indoor unit		Item code
15, 22, 28, 36, 45, 56, 60, 73, 90	106, 140, 160	b0
External static pressure of the rated air flow volume (Pa)		
150	150	00 15
140	140	00 14
130	130	00 13
120	120	00 12
100	110	00 11
70	100	00 08
60	70	00 06
50	50	00 05
30	30	00 03
10	10	00 01
No auto airflow volume setting		-001
Auto airflow volume setting		-002




\* Failure to set this parameter may result in decreased airflow and condensation.




### Indoor Fan Performance

		Item code "b0"												
		00 15	00 14	00 13	00 12	00 11	00 08	00 06	00 05	00 03	00 01			
		Cooling	Heating	Cooling	Heating	Cooling	Heating	Cooling	Heating	Cooling	Heating			
Tap	15	H	H											
	14			H	H									
	13	M	M		H	H								
	12					H	H							
	11			M			H	H						
	8		M					H	H					
	6	L	L		M	M	M		H	H				
	5						M	M		H	H			
	3			L	L	L	L	L	L	M	M	H	H	
	1		L	L				L	L	L	L	M	M	H
1-2									L	L	L	L	M	M
1-3											L	L		


Type 15, 22, 28, 36 and 45




Type 56




Type 60, 73




Type 90




Type 106



Type 140



Type 160



### • High Static Pressure Ducted (S-180, 224, 280ME2E5)

Choose one of the methods (selection of “a”, “b”, “c” within the range of dotted line as shown in the flowchart below) and make settings.

a. No setting changes:

When using as it is factory preset at shipment.

(If resetting after external static pressure setting once, it might be different from factory preset.)


b. Manual setting (on PCB):

This is static pressure setting excepting factory preset at shipment. Dip switch select method.

c. Manual setting (by wired remote controller):

Static pressure setting excepting factory preset at shipment.

### Flow of External Static Pressure



#### NOTE

(1) Refer to Table 2-9, 2-10, 2-11 and Fig. 2-10 for details on the relationship between the value of item code “5d” and the external static pressure.

(2) When set in group control (connecting multiple indoor units with one wired remote controller), set each indoor unit to item code “5d”.

When amending the setting after selecting [ b. Manual setting] (due to airflow path changes, etc.), it is necessary to cancel [b. Manual setting] (switching OFF positions).

When [b. Manual setting] has not been cancelled, [c. Manual setting] will be activated if selected, but [b. Manual setting] takes precedence when the power is switched back on after power outages, etc.

#### CAUTION

● **Make sure the external static pressure is in a range of specifications.**

**Then proceed the external static pressure setting.**

**Improper settings can cause noise, a shortage of airflow volume and water leakage.**

**Refer to Fig. 2-9 for the external static pressure setting range.**

● **Be sure to set the [External Static Pressure Setting] once again after amending the airflow path for the duct or air outlet after setting the external static pressure.**

## 2. Detailed Settings Function

### 1-1. How to Set on PC Board

1. Turn off the power breaker to halt the supply of electricity to the PC board.
2. Open the lid of the electrical component box and confirm the location where the Select switch on the indoor unit control PCB is placed. (Fig. 2-9)
3. Set the On/Off switches in the Off position which are now set in the On position. Select the positions of the Select SW001 switches respectively to make the desired external static pressure settings referring to the Table 2-8.

Table 2-8 External static pressure SW setting

External static pressure at the time of rated airflow volume		SW001		
224	280	TP6	TP3	TP1
270Pa	270Pa	ON 1	OFF 2	OFF 3
140Pa	140Pa	OFF 1	ON 2	OFF 3
60Pa	72Pa	OFF 1	OFF 2	ON 3




Fig. 2-9


### 1-2. Operating the Timer Remote Controller (CZ-RTC2)

#### How to set the external static pressure

1. Press and hold down the (CAN), and buttons simultaneously for 4 or more seconds. (SETTING, the Unit No., Item Code and Detailed Data will blink on the LCD display.)
2. The indoor unit numbers in the group control will be sequentially displayed whenever the Unit Select button is pressed . Only the fan motor for the selected indoor unit will operate during this time.
3. Specify the "5d" item code by pressing the / buttons for the temperature setting buttons and confirm the values. ("00 03" set at shipment)
4. Press the / buttons for the time to amend the values for the set data. Refer to Table 2-9 and Fig. 2-10 and select a value "00 06", "00 03" or "00 01".
5. Press the button. The display will stop blinking and remain illuminated.
6. Press the button. The fan motor will stop operating and the LCD display will return to the normal stop mode.

Table 2-9 Setting the external static pressure


Indoor unit		Item code
180, 224	280	5d
External static pressure of the rated air flow volume		
270 Pa	270 Pa	00 06
140 Pa	140 Pa	00 03
60 Pa	72 Pa	00 01



**NOTE:**

Failure to set this parameter may result in decreased airflow and condensation.

## 1-3. Operating the High-spec Wired Remote Controller (CZ-RTC3 / CZ-RTC5A)



Detailed settings		20:30 (THU)
Unit no.	Code no.	Set data
3-1	5D	0001
Sel.		Next

- Select the "Set data" by pressing the or button.  
Select one of the "Set data" among "0006", "0003" or "0001" according to the desired external static pressure setting by pressing the or button.  
Then press the button.  
(See the table below.)

Then press the button.

### How to set the external static pressure

- Keep pressing the , and buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.

Maintenance func		20:30 (THU)
1. Outdoor unit error data		
2. Service contact		
3. RC setting mode		
4. Test run		
Sel.		Page [] Confirm

- Press the or button to see each menu. If you wish to see the next screen instantly, press the or button. Select "8. Detailed settings" on the LCD display and press the button.

Maintenance func		20:30 (THU)
5. Sensor info.		
6. Servicing check		
7. Simple settings		
8. Detailed settings		
Sel.		Page [] Confirm

The "Detailed settings" screen appears on the LCD display.

Select the "Unit no." by pressing the or button for changes.

Detailed settings		20:30 (THU)
Unit no.	Code no.	Set data
3-1	10	0006
Sel.		Next

- Select the "Code no." by pressing the or button.  
Change the "Code no." to "5D" by pressing the or button (or keeping it pressed).

Table 2-10 Setting the external static pressure

Indoor unit		Item code
180, 224	280	5D
External static pressure of the rated air flow volume (Pa)		
270 Pa	270 Pa	0006
140 Pa	140 Pa	0003
60 Pa	72 Pa	0001

- Select the "Unit no." by pressing the or button and press the button. The "Exit detailed settings and restart?" (Detailed setting-end) screen appears on the LCD display. Select "YES" and press the button.

Exit detailed settings and restart?	
YES	NO
Sel. Next	



## 1-4. Operating the Timer Remote Controller (CZ-RTC4)

### How to set the external static pressure












1. Press and hold down the ,  and  buttons simultaneously for 4 or more seconds.  
( **SETTING**, the Unit No., Item Code and Detailed Data will blink on the LCD display.)
2. The indoor unit numbers in the group control will be sequentially displayed whenever the Unit Select button is pressed .  
Only the fan motor for the selected indoor unit will operate during this time.
3. Specify the “**5d**” item code by pressing the  /  buttons for the temperature setting buttons and confirm the values.  
(“**0003**” set at shipment )
4. Press the  /  buttons for the time to amend the values for the set data.  
Refer to Table 2-11 and Fig. 2-10 and select a value “**0006**”, “**0003**” or “**0001**”.
5. Press the  button.  
The display will stop blinking and remain illuminated.
6. Press the  button. The fan motor will stop operating and the LCD display will return to the normal stop mode.

Table 2-11 Setting the external static pressure

Indoor unit		Item code
180, 224	280	<b>5d</b>
External static pressure of the rated air flow volume		
270 Pa	270 Pa	<b>0006</b>
140 Pa	140 Pa	<b>0003</b>
60 Pa	72 Pa	<b>0001</b>



## Indoor Fan Performance

			Tap								
			①	②	③	④	⑤	⑥	⑦	⑧	⑨
Item code "5d"	0005	Cooling				L			M		H
		Heating				L			M		H
	0003	Setting at shipment	Cooling	L					M		H
		Heating	L						M		H
	0001	Cooling	L		M		H				
		Heating	L		M		H				






Fig. 2-10

● In the case of Fresh Air Intake Mode





Fig. 2-11

### • Slim Low Static Ducted (S-15~56MM1E5A)

Choose one of the methods (selection of “a”, “b”, “c” within the range of dotted line as shown in the flowchart below) and make settings.

a. No setting changes:

When using as it is factory preset at shipment.

(If resetting after external static pressure setting once, it might be different from factory preset.)


b. Manual setting (on PCB):

This is static pressure setting excepting factory preset at shipment. Dip switch select method.

c. Manual setting (by wired remote controller):

Static pressure setting excepting factory preset at shipment.

### Flow of External Static Pressure



#### NOTE

- (1) Refer to Table 2-13, 2-14, 2-15 and Fig. 2-13 for details on the relationship between the value of item code “5d” and the external static pressure.
- (2) When set in group control (connecting multiple indoor units with one wired remote controller), set each indoor unit to item code “5d”. When amending the setting after selecting [ b. Manual setting] (due to airflow path changes, etc.), it is necessary to cancel [b. Manual setting] (switching OFF positions).  
When [b. Manual setting] has not been cancelled, [c. Manual setting] will be activated if selected, but [b. Manual setting] takes precedence when the power is switched back on after power outages, etc.



#### CAUTION

- **Make sure the external static pressure is in a range of specifications. Then proceed the external static pressure setting. Improper settings can cause noise, a shortage of airflow volume and water leakage. Refer to Fig. 2-13 for the external static pressure setting range.**
- **Be sure to set the [External Static Pressure Setting] once again after amending the airflow path for the duct or air outlet after setting the external static pressure.**

## 2. Detailed Settings Function

### 1-1. How to Set on PC Board

1. Turn off the power breaker to halt the supply of electricity to the PC board.
2. Open the cover of the electrical box and confirm that there is the indoor unit control PC board in it.  
When using with high static pressure mode, set the indoor unit control PC board as shown in Fig. 2-12.
3. Connect the short circuit connector to the short circuit pin TP3 (2P: Yellow) of the indoor unit control board.
  - In the case of wired remote control setting, do not use the short circuit connector.

Table 2-12 External static pressure

Type	15	22	28	36	45	56
Standard (Pa) (shipment)	10		15		15	
High static pressure (Pa)	30		30		40	




Fig. 2-12


### 1-2. Operating the Timer Remote Controller (CZ-RTC2)

#### How to set the external static pressure

1. Press and hold down the (CAN/CEL), and buttons simultaneously for 4 or more seconds.  
(SETTING, the Unit No., Item Code and Detailed Data will blink on the LCD display.)
2. The indoor unit numbers in the group control will be sequentially displayed whenever the Unit Select button is pressed .  
Only the fan motor for the selected indoor unit will operate during this time.
3. Specify the "5d" item code by pressing the / buttons for the temperature setting buttons and confirm the values.  
("00 00" set at shipment)
4. Press the / buttons for the time to amend the values for the set data.  
Refer to Table 2-13 and Fig. 2-13 and select a value "00 03".
5. Press the button.  
The display will stop blinking and remain illuminated.
6. Press the button. The fan motor will stop operating and the LCD display will return to the normal stop mode.

Table 2-13 Setting the external static pressure

Indoor unit						Item code
15	22	28	36	45	56	
External static pressure of the rated air flow volume (Pa)						5d
10	15	15		00 00		
30	30	40		00 03		



**NOTE:**

Failure to set this parameter may result in decreased airflow and condensation.

## 1-3. Operating the High-spec Wired Remote Controller (CZ-RTC3 / CZ-RTC5A)



Detailed settings		20:30 (THU)
Unit no.	Code no.	Set data
3-1	5D	0001
Sel.		Next

- Select the "Set data" by pressing the or button.  
Select one of the "Set data" among "0003" according to the desired external static pressure setting by pressing the or button.  
Then press the button.  
(See the table below.)  
Then press the button.

### How to set the external static pressure

- Keep pressing the , , and buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.

Maintenance func		20:30 (THU)
1. Outdoor unit error data		
2. Service contact		
3. RC setting mode		
4. Test run		
Sel.		Page [] Confirm

- Press the or button to see each menu. If you wish to see the next screen instantly, press the or button. Select "8. Detailed settings" on the LCD display and press the button.

Maintenance func		20:30 (THU)
5. Sensor info.		
6. Servicing check		
7. Simple settings		
8. Detailed settings		
Sel.		Page [] Confirm

The "Detailed settings" screen appears on the LCD display.

Select the "Unit no." by pressing the or button for changes.

Detailed settings		20:30 (THU)
Unit no.	Code no.	Set data
3-1	10	0006
Sel.		Next

- Select the "Code no." by pressing the or button.  
Change the "Code no." to "5D" by pressing the or button (or keeping it pressed).

Table 1-14 Setting the external static pressure

Indoor unit						Item code
15	22	28	36	45	56	5D
External static pressure of the rated air flow volume (Pa)						
10		15		15		0000
30		30		40		0003

- Select the "Unit no." by pressing the or button and press the button. The "Exit detailed settings and restart?" (Detailed setting-end) screen appears on the LCD display. Select "YES" and press the button.

Exit detailed settings and restart?	
YES	NO

## 2. Detailed Settings Function

### 1-4. Operating the Timer Remote Controller (CZ-RTC4)

#### How to set the external static pressure












- Press and hold down the ,  and  buttons simultaneously for 4 or more seconds. (**SETTING**, the Unit No., Item Code and Detailed Data will blink on the LCD display.)
- The indoor unit numbers in the group control will be sequentially displayed whenever the Unit Select button is pressed . Only the fan motor for the selected indoor unit will operate during this time.
- Specify the “**Sd**” item code by pressing the  /  buttons for the temperature setting buttons and confirm the values. (“**0000**” set at shipment )
- Press the  /  buttons for the time to amend the values for the set data. Refer to Table 2-15 and Fig. 2-13 and select a value “**0003**”.
- Press the  button. The display will stop blinking and remain illuminated.
- Press the  button. The fan motor will stop operating and the LCD display will return to the normal stop mode.

Table 2-15 Setting the external static pressure

Item code	Set data	External static pressure of the rated air flow volume					
		Indoor unit type					
		15	22	28	36	45	56
<b>Sd</b>	<b>0000</b>	10 Pa	15 Pa	15 Pa			
	<b>0003</b>	30 Pa	30 Pa	40 Pa			



**NOTE:**

Failure to set this parameter may result in decreased airflow and condensation.

External static pressure's upper limit in high static pressure mode

Standard external static pressure's upper limit

Rated external static pressure in high static pressure mode

Lower static pressure in high static pressure mode

Rated external static pressure at shipment

Lower limit airflow

Upper limit airflow










Fig. 2-13

- The remote controller includes a number of servicing functions. Use these as needed for test runs and inspections.

#### ■ Timer Remote Controller CZ-RTC2




















Fig. 3-1








#### List of Servicing Functions

Functions	Description	Button operation	Reset operation	Unit status
Test run	Operation with forced thermostat ON	Press and hold the  button for 4 seconds or longer.		
Sensor temperature display	Temperature display from each sensor	Press and hold the  and  buttons for 4 seconds or longer.		Current operation is maintained.
Servicing check display	Alarm history display	Press and hold the  and  buttons for 4 seconds or longer.	Press the  button.	
Simple settings	Filter lifetime, operating mode priority, central control address, and other settings	Press and hold the  and  buttons for 4 seconds or longer.		
Detailed settings	System address, indoor unit address, central control address, and other settings	Press and hold the  ,  and  buttons for 4 seconds or longer.		
Automatic address	Automatic address setting based on command from the wired remote controller	Press and hold the  and the timer operation  buttons for 4 seconds or longer.	Automatic reset	Entire system stops.
Address change	Change of indoor unit address	Press and hold the  and the timer operation  buttons for 4 seconds or longer.	Press the  button.	



## ■ High-spec Wired Remote Controller CZ-RTC3 / CZ-RTC5A

Display of "maintenance function" screen

- ① Keep pressing the  ,  and  buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.
- ② Press the  or  button to see each menu. If you wish to see the next screen instantly, press the  or  button.







Fig. 3-2

### List of Servicing Functions

Functions	Description	Menu selection	Reset operation	Unit status
ECONAVI • CZ-KPU3A • CZ-CENSC1	Display from each sensor	0. ECONAVI info.		
Test run	Operation with forced thermostat ON	4. Test run	Press the  button.	
Sensor temperature display	Temperature display from each sensor	5. Sensor info		
Servicing check display	Alarm history display	6. Service check		
Simple settings	Filter lifetime, operating mode priority, central control address, and other settings	7. Simple settings	Press the  button. (Restart)	When settings are made from a remote controller, the indoor unit where that remote controller is connected stops.
Detailed settings	System address, indoor unit address, central control address, and other settings	8. Detailed settings		
Automatic address	Automatic address setting based on command from the wired remote controller	9. Auto address	Automatic reset	Entire system stops.
nanoe™ X (CZ-RTC5A only)	Display status of nanoe™ X	13. nanoe	Press the  button.	

## ■ Timer Remote Controller CZ-RTC4





Fig. 3-3





### List of Servicing Functions

Functions	Description	Button operation	Reset operation	Unit status
Test run	Operation with forced thermostat ON	Press and hold the  button for 4 seconds or longer.	Press the  button.	Current operation is maintained.
Sensor temperature display	Temperature display from each sensor	Press and hold the  and  buttons for 4 seconds or longer.		
Servicing check display	Alarm history display	Press and hold the  and  buttons for 4 seconds or longer.		
Simple settings	Filter lifetime, operating mode priority, central control address, and other settings	Press and hold the  and  buttons for 4 seconds or longer.	Automatic reset	When settings are made from a remote controller, the indoor unit where that remote controller is connected stops.
Detailed settings	System address, indoor unit address, central control address, and other settings	Press and hold the ,  and  buttons for 4 seconds or longer.		
Auto address	Auto address setting based on command from the wired remote controller	Press and hold the  and the timer operation  buttons for 4 seconds or longer.	Press the  button.	Entire system stops.
Address change	Change of indoor unit address	Press and hold the  and the timer operation  buttons for 4 seconds or longer.		




## ■ ECONAVI Display

When the  **ECONAVI** appears on the LCD display, the state of the sensor unit can be checked in the following method.



### <Procedure of CZ-RTC3 / CZ-RTC5A>

- ① Keep pressing the ,  and  buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.
- ② Select "0. ECONAVI info." on the LCD display and press the  button.




Maintenance func		20:30 (THU)
0. ECONAVI info.		
1. Outdoor unit error data		
2. Service contact		
3. RC. setting mode		
▼ Sel.	▶ Page	[↵] Confirm

- ③ Press the  or  button to see each menu. Select "Sensor unit info." on the LCD display and press the  button.

ECONAVI info.		20:30 (THU)
Setting info.		
Sensor unit info.		
ECONAVI Status	<input checked="" type="checkbox"/>	Normal
▲ Sel.	[↵] Check	

Select the "Unit no." by pressing the  or  button for changes.

ECONAVI info.		20:30 (THU)
Unit no.	Code no.	Data
▲	10	0002
<b>1</b>	11	0001
▼	12	0000
◄ Sel.	▶ Next	

Then press the  button. Display sensor information of the unit. Refer to the information by pressing the  or  button.




Fig. 3-4

Code no.		Description
ECONAVI sensor	ECONAVI panel	
11	21	Data shows the status of the ECONAVI sensor. 0000: The sensor is not connected. 0001: The sensor can detect human motion. 0002: The sensor is initializing. (The sensor cannot detect human motion. ) The initial setting is completed after about 90 seconds when switched on. 0003: Multiple sensor units are connected. Only one sensor unit per indoor group is connectable. 0004: The sensor is broken down. 0005: The floor temperature sensor is broken down. Data is automatically updated every 30 seconds.
12	22	In 30 seconds, data shows the number of times human motion was detected. Data is automatically updated every 30 seconds.
-	24	Data shows the floor temperature measured by the sensor. Data is automatically updated every 30 seconds.

#### How to Check Human Detection Sensor

- Step 1 Check that Code no.11 or 21 is showing "0001".
- Step 2 Make the sensor that can detect a person.  
 Move back and forth and around for about 10 seconds under sensor activation.
- Step 3 Check that Code no.12 or 22 can show "1" or more within 30 seconds after Step 2 is performed.
- Step 4 Make the sensor that cannot detect a person.  
 Exclude the persons or animals (an object to be detected) from the detection area.  
 If the remote controller is placed within the detection area of the ECONAVI sensor, an inspector must check motionless the display of the remote controller.
- Step 5 After a while, check that Code no.12 or 22 can show "0" . (For about 30 seconds to 2 minutes)





#### How to Check Floor Temperature Sensor


Code no. 24: There is no problem if data is within the range of -20 to 60.  
 If data shows -35, the floor temperature is broken down.

## Check of ECONAVI Operational Status


The status of ECONAVI operation can be checked instantly.  
It is available to check the operation when installing the indoor unit.


### <Procedure of CZ-RTC3 / CZ-RTC5A>

- ① Keep pressing the ,  and  buttons simultaneously for 4 or more seconds.  
The "Maintenance func" screen appears on the LCD display.
- ② Select "0. ECONAVI info." on the LCD display and press the  button.




- ③ Press the  or  button to see each menu.

Select "Status info." on the LCD display and press the  button.




- ④ There are four patterns of operational status display as shown below.

(1) Under normal operation



State of no energy-saving operation

(2) Under temperature shift



State of energy-saving (temperature shift) operation





Fig. 3-5

(3) Under suspension with absentee




State of energy-saving (suspended) operation

\*Shows that air conditioner operation was suspended because no person was detected for a certain period.

This state remains until operation is restarted.

(4) Under sensor communication error



Shows that the connected ECONAVI sensor is in error state.

## ■ Test Run Function

Operates the unit with the thermostat forced ON.

### <Procedure of CZ-RTC2>







- ① Press and hold the  button for 4 seconds or longer.
- ② "TEST" appears on the remote controller LCD display (Fig. 3-6).
- ③ Start operation.
- ④ Press the  button to return to normal remote controller display.









Fig. 3-6




### <Procedure of CZ-RTC3 / CZ-RTC5A>



- ① Keep pressing the , , and  buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.



- ② Press the  or  button to see each menu. If you wish to see the next screen instantly, press the  or  button. Select "4. Test run" on the LCD display and press the  button.





Change the display from OFF to ON by pressing the  or  button. Then press the  button.





CZ-RTC3 / CZ-RTC5A

Fig. 3-7



- ③ Press the  button. "TEST" will be displayed on the LCD display.



- ④ Press the  button. Test run will be started. Test run setting mode screen appears on the LCD display.




<Procedure of CZ-RTC4>

- ① Press and hold the  button for 4 seconds or longer.
- ② “TEST” appears on the remote controller LCD display (Fig. 3-8).
- ③ Press the  button to start the test run.

- The temperature cannot be adjusted in Test Run mode. (This mode places a heavy load on the machines. Therefore use it only when performing the test run.)
- The test run can be performed using the HEAT, COOL, or FAN operation modes.

**NOTE** The outdoor unit will not operate for approximately 3 minutes after the power is turned ON and after operation is stopped.

- If correct operation is not possible, an error code is displayed on the remote controller LCD display.

- ④ Press the  button to return to normal remote controller display.
- To prevent continuous test runs, this remote controller includes a timer function that cancels the test run after 60 minutes.
  - The operation is possible even if the cassette-type ceiling panel has not been installed. (“P09” display does not occur.)











Fig. 3-8

#### ■ Sensor Temperature Display Function (displayed regardless of whether unit is operating or stopped)

The procedure below displays the sensor temperatures from the remote controller, indoor unit, and outdoor unit on the remote controller.

##### <Procedure of CZ-RTC2>

- ① Press and hold the  and  buttons simultaneously for 4 seconds or longer.
- ② The unit No. "X-X" (main unit No.), item code "XX" (sensor address), and servicing monitor "00XX" (sensor temperature) are displayed on the remote controller LCD display. (See Fig. 3-9 at right.)
- ③ Press the temperature setting  /  buttons and select the item code to the address of the sensor to monitor.  
(For the relationships between the sensor addresses and sensor types, see the table of indoor and outdoor unit sensors on page 5-55.)
- ④ If group control is in effect, press the  button to select the unit to monitor.  
Press the temperature setting buttons to select the item code to change.
- ⑤ Press the  button to return to normal remote controller display.



\* Display shows a discharge temperature of 00XX at unit No. 1-1.  
In case, for example, the display shows "0085" in the figure above, a discharge temperature from the outdoor unit stands for 85°C.

**Fig. 3-9**

#### NOTE

The temperature display appears as "- - -" for units that are not connected.

\* If monitor mode is engaged while normal operation is in progress, only the parts of the LCD display shown in the figure will change. Other parts continue to display the same information as during normal operation.



## <Procedure of CZ-RTC3 / CZ-RTC5A>

- ① Keep pressing the , and buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.

Maintenance func		20:30 (THU)
1. Outdoor unit error data		
2. Service contact		
3. RC setting mode		
4. Test run		
▼ Sel.	▶ Page [↵]	Confirm

- ② Press the or button to see each menu. If you wish to see the next screen instantly, press the or button. Select "5. Sensor info." on the LCD display and press the button.

Maintenance func		20:30 (THU)
5. Sensor info.		
6. Servicing check		
7. Simple settings		
8. Detailed settings		
↕ Sel.	◀▶ Page [↵]	Confirm

Select the "Unit no." by pressing the or button for changes.

Sensor info.		20:30 (THU)
Unit no.	Code no.	Data
▲	00	0026
1-1	01	0028
▼	02	0026
↕ Sel.	▶ Next	

Then press the button. Display sensor information of the unit.

Sensor info.		20:30 (THU)
Unit no.	Code no.	Data
1-1	00	0026
	01	0028
	02	0026
↕ Scroll		

Refer to the information by pressing the or button.











Fig. 3-10

## <Procedure of CZ-RTC4>

- ① Press and hold the  and  buttons simultaneously for 4 seconds or longer.
- ② The unit No. "X-X" (main unit No.), item code "XX" (sensor address), and servicing monitor "00XX" (sensor temperature) are displayed on the remote controller LCD display. (See Fig. 3-11 at right.)
- ③ Press the temperature setting  /  buttons and select the item code to the address of the sensor to monitor.
- ④ If group control is in effect, press the  button to select the unit to monitor.  
Press the temperature setting buttons to select the item code to change.
- ⑤ Press the  button to return to normal remote controller display.



\* Display shows a discharge temperature of 00XX at unit No. 1-1.

**Fig. 3-11**

### NOTE

The temperature display appears as "- - -" for unit that are not connected.

\* If monitor mode is engaged while normal operation is in progress, only the parts of the LCD display shown in the figure will change. Other parts continue to display the same information as during normal operation.

Indoor unit sensors	
00	Room temp. controlled*
01	Remote controller temp.
02	Indoor unit intake temp. (TA)
03	Indoor unit heat exchanger temp. E1 (E1)
04	—
05	Indoor unit heat exchanger temp. E3 (E3)
06	Discharge air temp. (BL)
07	Discharge air temp. setting
08	Indoor unit MOV pulse (MOV)

Outdoor unit sensors
* Refer to the Service Manual of Outdoor Unit.

\*Room temp. controlled: = Controlled room temperature

•When body thermostat controlled:

Controlled room temperature = Indoor unit intake temp. (TA) – Intake temperature shift (\*1)

•Remote control thermostat controlled:

Controlled room temperature = Remote controller temp.

\*1 Intake temperature shift: This is the shift value considered the temperature difference between the upper area and lower area of the room in heating mode.

It is the value of the code "06" in the indoor unit's EEPROM setting.


Cooling mode: = 0

## nanoe™ X Display


When the appears on the remote controller (CZ-RTC5A), the status of the nanoe™ X can be checked in the following way.

### <Procedure of CZ-RTC5A>


- ① Switch On the earth leakage circuit breaker.
- ② Wait until the remote control display returns to normal.



- ③ Operate the unit in FAN mode.



- ④ While operating in FAN mode (more than 5 minutes have elapsed), press the , and buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.



- ⑤ Press the or button to see each menu. Select "13. nanoe" on the LCD display and press the button.




Fig. 3-12

- ⑥ Check that the nanoe™ X module status is "Normal". The indoor unit on the display can be scrolled up or down using / buttons.

nanoe		20:30 (THU)
Unit no.	Status	
1- 1	Normal	
1- 2	Not connected	
1- 3	Unsupported	
▼ Scroll		

The nanoe™ X module status of all indoor units will be displayed.

Normal : The nanoe™ X module is operating normally.

Unsupported : The indoor unit is not available to the nanoe™ X function.

\*1-1 and 1-2 represent the unit number.

\*In the case of "Unsupported", select "8. Detailed settings" and check the setting data of the Code no. 9.

\*If the setting data is "0000", the nanoe™ X module is not recognized. Check the status of the connection.

If the display other than "Normal" or "Unsupported" appears, check the Step ⑦ next page.


- ⑦ In the case of the nanoe™ X module status other than "Normal" or "Unsupported"  
 If the menu "13. nanoe" is not displayed or the module status becomes other than "Normal" or "Unsupported" even though the nanoe™ X module is connected, there is a probability that the following symptoms happen.

Display	Symptom	Countermeasure
Display	The probability of occurrence of nanoe™ X is deviated from the room temperature and humidity conditions. Outside the range of temperature: Below 5°C or over 35°C Outside the range of humidity: Over 86%	There is no abnormality in the nanoe™ X module. Use in the range of appropriate temperature and humidity.
Abnormal humidity sensor	Humidity sensor not connected or sensor failure	Check if connected to the indoor unit PCB of the humidity sensor or replace the sensor.
Disconnection failure	The wiring between the indoor unit and nanoe™ X module is not connected.	Specialize the target indoor unit and check the connection to the indoor unit PCB of the nanoe™ X module.
Not connected	There is no abnormality in the nanoe™ X module. Use in the range of appropriate room temperature and humidity.	

\*Specialization of the indoor unit can be checked by the operation of the airflow.

Checking method:

1. Stop the maintenance function.

Press the  button to show the maintenance func display. Then press the  button.

2. Operate the airflow.

Select the Unit no. under the  "2. Airflow setting". Make the airflow setting.

The unit which is corresponded to the preset flap operation will become the target unit.

When the unit is specialized, switch off the earth leakage circuit breaker and unplug the connector of the nanoe™ X module wiring from the PCB. Then plug it in again. Switch on the earth leakage circuit breaker and once again check the Steps 1 to 3. Then check the status by selecting the menu "13. nanoe". If "Disconnection failure" or "Not connected" appears on the display, it is necessary to replace the nanoe™ X module with a new one.



## 6. TROUBLE DIAGNOSIS

\* Refer to the Service Manual of Outdoor Unit

However, refer to page 5-53 operations in the high-spec wired remote controller (CZ-RTC3 / CZ-RTC5A) of "Sensor temperature display function".








## 7. TEST RUN from the remote controller


- 1. Test Run ..... 7-2
- 2. Auto Address Setting ..... 7-4






Regarding the detailed settings for the test run, refer to the service manual for each outdoor unit. If operating the high-spec wired remote controller (CZ-RTC3 / CZ-RTC5A / CZ-RTC4) is necessary, follow the procedure described below.


## 7-1. Test Run




### <Procedure of CZ-RTC3 / CZ-RTC5A>

- Keep pressing the ,  and  buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.



- Press the  or  button to see each menu. If you wish to see the next screen instantly, press the  or  button. Select "4. Test run" on the LCD display and press the  button.



Change the display from OFF to ON by pressing the  or  button. Then press the  button.









Fig. 1

- Press the  button. "TEST" will be displayed on the LCD display.





- Press the  button. Test run will be started. Test run setting mode screen appears on the LCD display.




# 1. Test Run


## <Procedure of CZ-RTC4>

1. Press the remote controller  button for 4 seconds or longer.  
Then press the  button.
- “TEST” appears on the LCD display while the test run is in progress.
- The temperature cannot be adjusted when in Test Run mode.  
(This mode places a heavy load on the machines.  
Therefore use it only when performing the test run.)
2. The test run can be performed using the HEAT, COOL, or FAN operation modes.

### NOTE




The outdoor units will not operate for approximately 3 minutes after the power is turned ON and after operation is stopped.






3. If correct operation is not possible, a code is displayed on the remote controller LCD display.  
(Refer to “Table of Self-Diagnostic Functions” and correct the problem.)
  4. After the test run is completed, press the  button again.  
Check that “TEST” disappears from the LCD display.  
(To prevent continuous test runs, this remote controller includes a timer function that cancels the test run after 60 minutes.)
- \* If the test run is performed using the wired remote controller, operation is possible even if the cassette-type ceiling panel has not been installed. (“P09” display does not occur.)






## 7-2. Auto address setting

### <Procedure of CZ-RTC3 / CZ-RTC5A>

① Keep pressing the ,  and  buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.

② Press the  or  button to see each menu. If you wish to see the next screen instantly, press the  or  button. Select "9. Auto address" on the LCD display and press the  button.

 Maintenance func	20:30 (THU)
<b>9. Auto address</b>	
10. Set elec. consumption	
11. Set touch key	
12. Check touch key	
↕ Sel. ◀ Page [↩] Confirm	

③ The "Auto address" screen appears on the LCD display. Change the "Code no." to "A1" by pressing the  or  button.

Auto address	20:30 (THU)
Code no.	O/D unit no.
<b>A1</b>	1
↕ Sel. ▶ Next	










④ Select the "O/D unit no." by pressing the  or  button. Select one of the "O/D unit no." for automatic address by pressing the  or  button. Then press the  button. Approximately about 10 minutes are required. When automatic address setting is completed, the units return to normal stopped status.









Fig. 2

### ■ Checking indoor unit addresses



① Keep pressing the ,  and  buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.

 Maintenance func	20:30 (THU)
<b>1. Outdoor unit error data</b>	
2. Service contact	
3. RC setting mode	
4. Test run	
↕ Sel. ▶ Page [↩] Confirm	

② Press the  or  button to see each menu. If you wish to see the next screen instantly, press the  or  button. Select "7. Simple settings" on the LCD display and press the  button.

 Maintenance func	20:30 (THU)
5. Sensor info.	
6. Servicing check	
<b>7. Simple settings</b>	
8. Detailed settings	
↕ Sel. ◀ ▶ Page [↩] Confirm	

The "Simple settings" screen appears on the LCD display.

Select the "Unit no." by pressing the  or  button for changes.

Simple settings	20:30 (THU)	
Unit no.	Code no.	Set data
<b>3-1</b>	01	0001
↕ Sel. ▶ Next		

The indoor unit fan operates only at the selected indoor unit.


## 2.Auto address setting

### <Procedure of CZ-RTC4>

\* Automatic address setting in Cooling mode cannot be done from the remote controller.

#### NOTE

- Selecting each refrigerant system individually for automatic address setting
- Automatic address setting for each system : Item code "A1"



1. Press the remote controller timer time button and button at the same time.  
(Press and hold for 4 seconds or longer.)
2. Next, press either the temperature setting / button. (Check that the item code is "A1".)
3. Use either the or button to set the system No. to perform automatic address setting.
4. Then press the button.  
(Automatic address setting for one refrigerant system begins.) (When automatic address setting for one system is completed, the system returns to normal stopped status.)  
<Approximately 4 – 5 minutes is required.>  
(During automatic address setting, " **SETTING** " is displayed on the remote controller.  
This message disappears when automatic address setting is completed.)
5. Repeat the same steps to perform automatic address setting for each successive system.

### • Request concerning recording the indoor/outdoor unit combination Nos.

After automatic address setting has been completed, be sure to record them for future reference.

List the outdoor main unit system address and the addresses of the indoor units in that system in an easily visible location (next to the nameplate), using a permanent marking pen or similar means that cannot be abraded easily.


Example: (Outdoor) 1 - (Indoor) 1-1, 1-2, 1-3...  
(Outdoor) 2 - (Indoor) 2-1, 2-2, 2-3...

These numbers are necessary for later maintenance. Please be sure to indicate them.

### • Checking indoor unit addresses

#### <If 1 indoor unit is connected to 1 remote controller>


1. Press and hold the button and button for 4 seconds or longer (simple settings mode).
2. The address is displayed for the indoor unit that is connected to the remote controller.  
(Only the address of the indoor unit that is connected to the remote controller can be checked.)
3. Press the button again to return to normal remote controller mode.



Number changes to indicate which indoor unit is currently selected.  
Indoor unit address

#### <If multiple indoor units are connected to 1 remote controller (group control)>

1. Press and hold the button and button for 4 seconds or longer (simple settings mode).
2. "ALL" is displayed on the remote controller.
3. Next, press the button.
4. The address is displayed for 1 of the indoor units which is connected to the remote controller. Check that the fan of that indoor unit starts and that air is discharged.
5. Press the button again and check the address of each indoor unit in sequence.
6. Press the again to return to normal remote controller mode.



Number changes to indicate which indoor unit is currently selected.  
Indoor unit address

