



B1	Supply air temperature sensor	CW	Water cooler	QS1	Main switch	V1	Supply air fan
B2	Extract temperature sensor	DX	Cooler	dP1, dP2	Differential pressure switch for filter	V2	Exhaust air fan
B3	Outdoor temperature sensor	FG1	Supply air damper actuator	RG1	Main controller	LP	Low pressure protection
B4	Exhaust temperature sensor	FG2	Extract air damper actuator	RG2	Extension module	HP	High pressure protection
B5	Return water sensor	HE	Electric heater	RT	Rotary Heat Exchanger	SVD	Solenoid valve
B6, B7, B13	Air pressure sensor	HW	Water heater coil	S1	Heating water pump	SVR	Four-way valve
B8	Airquality, CO ₂ sensor	HM	Humidifier	S2	Cooling water pump		
B9	Humidity sensor	M1	Rotor motor	TG1	Hot water mixing valve actuator		
B15	Internal supply air temperature sensor	P1	Compressor	TG2	Cold water mixing valve actuator		
CW	Water cooler	PF	Air filter	VP	Remote control panel	FUNCTIONAL DIAGRAM RHP	