



Terminal	Signal / Component	Wiring
VP	Control panel	4x0.22mm²
1-12	MODBUS RS485 connection	3x0.5mm²
13-14	External control	5x0.5mm²
15-16	External stop	2x0.5mm²
17-18	Fire system	2x0.5mm²
19-20	OVR control	2x0.5mm²
21-22	Common	2x0.5mm²
23-24	Return water temp. sensor	2x0.5mm²
25-26	Supply temp. sensor	2x0.5mm²
27-28	Humidifier control	2x0.5mm²
29-30	DX 0-10V control	2x0.5mm²
31-32	Hot water mixing valve actuator	2x0.5mm²
33-34	Cooling water pump 230VAC	2x0.75mm²
35-36	Heating water pump 230VAC	2x0.75mm²
37-38	Humidity sensor	3x0.5mm²
39-40	Air quality sensor	3x0.5mm²
41-42	Exhaust air pressure sensor	3x0.5mm²
43-44	Supply air pressure sensor	3x0.5mm²
45-46	Supply/exhaust air damper actuator	3x0.5mm²
47-48	Run Alarm Common	3x0.5mm²
49-50	Heating Cooling Operation Common	3x0.5mm²
51-52	~230V	2x0.75mm²

400VAC

